

PortSIP VoIP SDK Manual for Windows

Version 18
1/27/21

Table of Contents

Welcome to PortSIP VoIP SDK For Windows	4
Getting Started	4
Contents	4
SDK User Manual	4
Website	4
Support	4
Frequently Asked Questions	4
1. What is the difference between PortSIP VoIP SDK and PortSIP VoIP SDK?.....	4
2. Where can I download the PortSIP VoIP SDK for test?.....	5
3. How can I compile the sample project?	5
4. How can I create a new project with PortSIP VoIP SDK?	5
C#/VB.NET:	5
VC++:.....	5
5. How can I test the P2P call (without SIP server)?	5
6. Is the SDK thread safe?.....	6
7. Does the SDK support native 64-bit?	6
Module Index	7
Namespace Index	8
Class Index	9
Module Documentation.....	10
SDK functions	10
Initialize and register functions.....	10
NIC and local IP functions.....	12
Audio and video codecs functions	17
Additional setting functions	20
Audio and video functions	26
Access SIP message header functions	28
Call functions	32
Refer functions	37
Send audio and video stream functions.....	39
RTP packets, Audio stream and video stream callback functions	42
Record functions	43
Play audio and video file to remote functions.....	44
Conference functions	47
RTP and RTCP QOS functions.....	49
RTP statistics functions.....	50
Audio effect functions.....	51
Send OPTIONS/INFO/MESSAGE functions.....	54
Presence functions.....	58
Device Manage functions.....	60
SDK Callback events	64
Register events	64
Call events.....	65
Refer events.....	69
Signaling events	70
MWI events.....	71
DTMF events	72
INFO/OPTIONS message events.....	73
Presence events	74
Play audio and video file finished events.....	76
RTP callback events.....	77
Audio and video stream callback events	78
PortSIP	80
Class Documentation	85
PortSIP.PortSIP_Errors.....	85
PortSIP.PortSIPLib	88

PortSIP.SIPCallbackEvents	98
Index.....	100

Welcome to PortSIP VoIP SDK For Windows

Create your SIP-based application for multiple platforms (iOS, Android, Windows, macOS and Linux) with our SDK.

The rewarding [PortSIP](#) VoIP SDK is a powerful and versatile set of tools that dramatically accelerate SIP application development. It includes a suite of stacks, SDKs, and some Sample projects, with each of them enables developers to combine all the necessary components to create an ideal development environment for every application's specific needs.

The [PortSIP](#) VoIP SDK complies with IETF and 3GPP standards, and is IMS-compliant (3GPP/3GPP2, TISPAN and PacketCable 2.0). These high performance SDKs provide unified API layers for full user control and flexibility.

Getting Started

You can download [PortSIP](#) VoIP SDK Sample projects at our [Website](#). Samples include demos for VC++, C#, VB.NET, Delphi XE, XCode (for iOS and macOS), Eclipse (Java for Android) with the sample project source code provided (with SDK source code exclusive). The sample projects demonstrate how to create a powerful SIP application with our SDK easily and quickly.

Contents

The sample package for downloading contains almost all of materials for [PortSIP](#) SDK: documentation, Dynamic/Static libraries, sources, headers, datasheet, and everything else a SDK user might need!

SDK User Manual

To be started with, it is recommended to read the documentation of [PortSIP](#) VoIP SDK, [SDK User Manual page](#), which gives a brief description of each API function.

Website

Some general interest or often changing [PortSIP](#) SDK information will be posted on the [PortSIP website](#) in real time. The release contains links to the site, so while browsing you may see occasional broken links if you are not connected to the Internet. To be sure everything needed for using the [PortSIP](#) VoIP SDK has been contained within the release.

Support

Please send email to our [Support team](#) if you need any help.

Frequently Asked Questions

1. What is the difference between PortSIP VoIP SDK and PortSIP VoIP SDK?

The [PortSIP VoIP SDK](#) is free, but was limited to works with [PortSIP PBX](#); The [PortSIP VoIP SDK](#) is not free that can works with any 3rd SIP based PBX. The UC SDK also have a lot of unique features than the VoIP SDK which provided by [PortSIP PBX](#).

2. Where can I download the PortSIP VoIP SDK for test?

All sample projects of the PortSIP VoIP SDK can be found and downloaded at:
<https://www.portsip.com/download-portsip-voip-sdk/>

3. How can I compile the sample project?

1. Download the sample project from [PortSIP](#) website.
2. Extract the .zip file.
3. Open the project with your IDE: C#, VB.NET, VC++: Visual Studio 2012 or higher.
4. Compile the sample project directly. The trial version SDK allows a 2-3 minutes conversation.

4. How can I create a new project with PortSIP VoIP SDK?

C#/VB.NET:

- ```
1) Download the Sample project and extract it for C#/VB.NET.
2) Create a new "Windows application" project.
3) Copy the PortSIP_sdk.dll to project output directory: bin\release and bin\debug.
4) Copy the "PortSIP" folder to project folder and add into Solution.
5) Inherit the interface "SIPCallbackEvents" to process the callback events.
6) Right-click the project, choose "Properties". Click "Build" tab, and then check the
"Allow unsafe code" checkbox.
```

For more details please read the Sample project source code.

### **VC++:**

- ```
1) Download and extract the sample project.  
2) Create a new "MFC Application" project.  
3) Copy the PortSIP_sdk.dll to project output directories.  
4) Copy the "include/PortSIPLib" folder to project folder and add the ".hxx" files into  
project.  
5) Copy the "lib" folder to project folder and link "PortSIP_sdk.lib" into project.
```

For more details please read the Sample project source code.

5. How can I test the P2P call (without SIP server)?

1. Download and extract the SDK sample project ZIP file, compile and run the "P2PSample" project.
2. Run the P2Psamp on two devices. For example, run it on device A and device B, and IP address for A is 192.168.1.10, IP address for B is 192.168.1.11.
3. Enter a user name and password on A. For example, user name 111, and password aaa (you can enter anything for the password as the SDK will ignore it). Enter a user name and password on B, for example: user name 222, password aaa.
4. Click the "Initialize" button on A and B. If the default port 5060 is already in use, the P2PSample will prompt "Initialize failure". In case of this, please click the "Uninitialize" button and change the local port, and click the "Initialize" button again.
5. The log box will appear "Initialized." if the SDK is successfully initialized.
6. To make call from A to B, enter: sip:[222@192.168.1.11](sip:222@192.168.1.11) and click "Dial" button; while to make call from B to A, enter: sip:[111@192.168.1.10](sip:111@192.168.1.10).

6. Is the SDK thread safe?

Yes, the SDK is thread safe. You can call any of the API functions without the need to consider the multiple threads. Note: the SDK allows to call API functions in callback events directly - except for the "onAudioRawCallback", "onVideoRawCallback", "onRTPPacketCallback" callbacks.

7. Does the SDK support native 64-bit?

Yes, both 32-bit and 64-bit are supported for SDK.

Module Index

Modules

Here is a list of all modules:

SDK functions.....	10
Initialize and register functions	10
NIC and local IP functions	12
Audio and video codecs functions.....	17
Additional setting functions.....	20
Audio and video functions.....	26
Access SIP message header functions	28
Call functions.....	32
Refer functions.....	37
Send audio and video stream functions	39
RTP packets, Audio stream and video stream callback functions.....	42
Record functions.....	43
Play audio and video file to remote functions	44
Conference functions	47
RTP and RTCP QOS functions	49
RTP statistics functions	50
Audio effect functions	51
Send OPTIONS/INFO/MESSAGE functions	54
Presence functions	58
Device Manage functions.	60
SDK Callback events	64
Register events.....	64
Call events	65
Refer events	69
Signaling events.....	70
MWI events	71
DTMF events	72
INFO/OPTIONS message events	73
Presence events.....	74
Play audio and video file finished events	76
RTP callback events	77
Audio and video stream callback events	78

Namespace Index

Packages

Here are the packages with brief descriptions (if available):

<u>PortSIP</u>	80
--------------------------------	-------	----

Class Index

Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

<u>PortSIP.PortSIP Errors</u>	85
<u>PortSIP.PortSIPLib</u>	88
<u>PortSIP.SIPCallbackEvents</u>	98

Module Documentation

SDK functions

SDK functions.

Modules

- [Initialize and register functions](#)
Initialize and register functions.
- [NIC and local IP functions](#)
- [Audio and video codecs functions](#)
- [Additional setting functions](#)
- [Audio and video functions](#)
- [Access SIP message header functions](#)
- [Call functions](#)
- [Refer functions](#)
- [Send audio and video stream functions](#)
- [RTP packets, Audio stream and video stream callback functions](#)
- [Record functions](#)
- [Play audio and video file to remote functions](#)
- [Conference functions](#)
- [RTP and RTCP QOS functions](#)
- [RTP statistics functions](#)
- [Audio effect functions](#)
- [Send OPTIONS/INFO/MESSAGE functions](#)
- [Presence functions](#)
- [Device Manage functions.](#)

Detailed Description

SDK functions.

Initialize and register functions

Initialize and register functions.

Functions

- Int32 [PortSIP.PortSIPLib.initialize](#) ([TRANSPORT_TYPE](#) transportType, String localIp, Int32 localSIPPort, [PORTSIP_LOG_LEVEL](#) logLevel, String logFilePath, Int32 maxCallSessions, String sipAgentString, Int32 audioDeviceLayer, Int32 videoDeviceLayer, String TLSCertificatesRootPath, String TLSCipherList, Boolean verifyTLSCertificate)
Initialize the SDK.
- void [PortSIP.PortSIPLib.unInitialize](#) ()
Un-initialize the SDK and release resources.
- Int32 [PortSIP.PortSIPLib.getVersion](#) (out Int32 majorVersion, out Int32 minorVersion)
Get the current version number of the SDK.

- Int32 [PortSIP.PortSIPLib.setLicenseKey](#) (String key)
Set the license key. It must be called before setUser function.
-

Detailed Description

Initialize and register functions.

Function Documentation

```
Int32 PortSIP.PortSIPLib.initialize (TRANSPORT\_TYPE transportType, String localIp,
Int32 localSIPPort, PORTSIP\_LOG\_LEVEL logLevel, String filePath, Int32
maxCallSessions, String sipAgentString, Int32 audioDeviceLayer, Int32
videoDeviceLayer, String TLSCertificatesRootPath, String TLSCipherList, Boolean
verifyTLSCertificate)
```

Initialize the SDK.

Parameters

<i>transport</i>	Transport for SIP signaling. TRANSPORT_PERS is the PortSIP private transport for anti SIP blocking. It must be used with PERS.
<i>localIP</i>	The local computer IP address to be bound (for example: 192.168.1.108). It will be used for sending and receiving SIP messages and RTP packets. If this IP is passed in IPv6 format, the SDK will be using IPv6. If you want the SDK to choose correct network interface (IP) automatically, please pass the "0.0.0.0"(for IPv4) or ":" (for IPv6).
<i>localSIPPort</i>	The SIP message transport listener port, for example: 5060.
<i>logLevel</i>	Set the application log level. The SDK will generate "PortSIP_Log.datatime.log" file if the log enabled.
<i>filePath</i>	The log file path. The path (folder) MUST be existent.
<i>maxCallLines</i>	Theoretically, unlimited lines could be supported depending on the device capability. For SIP client recommended value ranges 1 - 100;
<i>sipAgent</i>	The User-Agent header to be inserted into SIP messages.
<i>audioDeviceLayer</i>	Specify the audio device layer to be used: 0 = Use the OS default device. 1 = Virtual device, usually use this for the device which has no sound device installed.
<i>videoDeviceLayer</i>	Specifies the video device layer that should be used: 0 = Use the OS default device. 1 = Use Virtual device. Usually use this for the device which has no camera installed.
<i>TLSCertificatesRootPath</i>	Specify the TLS certificate path, from which the SDK will load the certificates automatically. Note: On Windows, this path will be ignored, and SDK will read the certificates from Windows certificates stored area instead.
<i>TLSCipherList</i>	Specify the TLS cipher list. This parameter is usually passed as empty so that the SDK will offer all available ciphers.
<i>verifyTLSCertificate</i>	Indicate if SDK will verify the TLS certificate. By setting to false, the SDK will not verify the validity of TLS certificate.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code

Int32 PortSIP.PortSIPLib.getVersion (out Int32 *majorVersion*, out Int32 *minorVersion*)

Get the current version number of the SDK.

Parameters

<i>majorVersion</i>	Return the major version number.
<i>minorVersion</i>	Return the minor version number.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setLicenseKey (String *key*)

Set the license key. It must be called before setUser function.

Parameters

<i>key</i>	The SDK license key, please purchase from PortSIP .
------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

NIC and local IP functions

Functions

- Int32 [PortSIP.PortSIPLib.getNICNums](#) ()
Get the Network Interface Card numbers.
- Int32 [PortSIP.PortSIPLib.getLocalIpAddress](#) (Int32 index, StringBuilder ip, Int32 ipSize)
Get the local IP address by Network Interface Card index.
- Int32 [PortSIP.PortSIPLib.setUser](#) (String userName, String displayName, String authName, String password, String sipDomain, String sipServerAddr, Int32 sipServerPort, String stunServerAddr, Int32 stunServerPort, String outboundServerAddr, Int32 outboundServerPort)
Set user account info.
- void [PortSIP.PortSIPLib.removeUser](#) ()
Remove the user. It will un-register from SIP server given that the user is already registered.
- Int32 [PortSIP.PortSIPLib.setDisplayName](#) (String displayName)
Set the display name of user.

- Int32 [PortSIP.PortSIPLib.setInstanceId](#) (String uuid)
Set outbound (RFC5626) instanceId to be used in contact headers.
- Int32 [PortSIP.PortSIPLib.registerServer](#) (Int32 expires, Int32 retryTimes)
Register to SIP proxy server (login to server).
- Int32 [PortSIP.PortSIPLib.unRegisterServer](#) ()
Un-register from the SIP proxy server.
- Int32 [PortSIP.PortSIPLib.enableRport](#) (Boolean enable)
Enable/disable rport(RFC3581).
- Int32 [PortSIP.PortSIPLib.enableEarlyMedia](#) (Boolean enable)
Enable/disable Early Media.
- Int32 [PortSIP.PortSIPLib.enableReliableProvisional](#) (Boolean enable)
Enable/disable PRACK.
- Int32 [PortSIP.PortSIPLib.enable3GppTags](#) (Boolean enable)
Enable/disable the 3Gpp tags, including "ims.icsi.mmTEL" and "g.3gpp.smsip".
- void [PortSIP.PortSIPLib.enableCallbackSignaling](#) (Boolean enableSending, Boolean enableReceived)
Enable/disable to callback the SIP messages.
- Int32 [PortSIP.PortSIPLib.enableRtpCallback](#) (Int32 callbackObject, Int32 sessionId, Int32 mediaType, Int32 directionMode)
Set the RTP callbacks to allow access to the sent and received RTP packets. The onRTPPacketCallback events will be triggered.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.getNICNums ()

Get the Network Interface Card numbers.

Returns

If the function succeeds, it will return the NIC numbers which is greater than or equal to 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.getLocallpAddress (Int32 *index*, StringBuilder *ip*, Int32 *ipSize*)

Get the local IP address by Network Interface Card index.

Parameters

<i>index</i>	The IP address index. For example, if the PC has two NICs, and we wish to obtain the second NIC IP. Set this parameter to 1 and the first NIC IP index is 0.
<i>ip</i>	The buffer that is used to receive the IP.
<i>ipSize</i>	The IP buffer size, which cannot be less than 32 bytes.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setUser (String *userName*, String *displayName*, String *authName*, String *password*, String *sipDomain*, String *sipServerAddr*, Int32 *sipServerPort*, String *stunServerAddr*, Int32 *stunServerPort*, String *outboundServerAddr*, Int32 *outboundServerPort*)

Set user account info.

Parameters

<i>userName</i>	Account (User name) of the SIP. Usually provided by an IP-Telephony service provider.
<i>displayName</i>	The display name of user. You can set it as your like, such as "James Kend". It's optional.
<i>authName</i>	Authorization user name (usually equal to the username).
<i>password</i>	The password of user. It's optional.
<i>locallp</i>	The local computer IP address to be bound. For example: 192.168.1.108. It will be used for sending and receiving SIP message and RTP packet. If pass this IP as the IPv6 format, the SDK will use IPv6.
<i>localSipPort</i>	The SIP message transport listener port. For example: 5060.
<i>userDomain</i>	User domain; this parameter is optional that allows to pass an empty string if you are not using the domain.
<i>sipServer</i>	SIP proxy server IP or domain. For example: xx.xxx.xx.x or sip.xxx.com.
<i>sipServerPort</i>	Port of the SIP proxy server. For example: 5060.
<i>stunServer</i>	Stun server used for NAT traversal. It's optional and can pass empty string to disable STUN.
<i>stunServerPort</i>	STUN server port. It will be ignored if the outboundServer is empty.
<i>outboundServer</i>	Outbound proxy server. For example: sip.domain.com. It's optional and allows to pass a empty string if not using outbound server.
<i>outboundServerPort</i>	Outbound proxy server port, it will be ignored if the outboundServer is empty.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setDisplayName (String *displayName*)

Set the display name of user.

Parameters

<i>displayName</i>	that will appear in the From/To Header.
--------------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setInstanceId (String *uuid*)

Set outbound (RFC5626) instanceId to be used in contact headers.

Parameters

<i>uuid</i>	The ID that will appear in the contact header. Please make sure it's a unique ID.
-------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.registerServer (Int32 *expires*, Int32 *retryTimes*)

Register to SIP proxy server (login to server).

Parameters

<i>expires</i>	Registration refresh Interval in seconds with maximum 3600. It will be inserted into SIP REGISTER message headers.
<i>retryTimes</i>	The retry times if failed to refresh the registration. If it's set to be less than or equal to 0, the retry will be disabled and onRegisterFailure callback triggered when retry failed.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code. If registration to server succeeded, onRegisterSuccess will be triggered, otherwise onRegisterFailure triggered.

Int32 PortSIP.PortSIPLib.unRegisterServer ()

Un-register from the SIP proxy server.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.enableRport (Boolean *enable*)

Enable/disable rport(RFC3581).

Parameters

<i>enable</i>	Set to true to enable the SDK to support rport. By default it is enabled.
---------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.enableEarlyMedia (Boolean enable)

Enable/disable Early Media.

Parameters

<i>enable</i>	Set to true to enable the SDK to support Early Media. By default Early Media is disabled.
---------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.enableReliableProvisional (Boolean enable)

Enable/disable PRACK.

Parameters

<i>enable</i>	Set to true to enable the SDK to support PRACK. The PRACK is disabled by default.
---------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.enable3GppTags (Boolean enable)

Enable/disable the 3Gpp tags, including "ims.icci.mmtel" and "g.3gpp.smsip".

Parameters

<i>enable</i>	Set to true to enable SDK to support 3Gpp tags.
---------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

void PortSIP.PortSIPLib.enableCallbackSignaling (Boolean enableSending, Boolean enableReceived)

Enable/disable to callback the SIP messages.

Parameters

<i>enableSending</i>	Set as true to enable to callback the sent SIP messages, or false to disable. Once enabled, the "onSendingSignaling" event will be triggered when the SDK sends a SIP message.
<i>enableReceived</i>	Set as true to enable to callback the received SIP messages, or false to disable. Once enabled, the "onReceivedSignaling" event will be triggered when the SDK receives a SIP message.

Int32 PortSIP.PortSIPLib.enableRtpCallback (Int32 *callbackObject*, Int32 *sessionId*, Int32 *mediaType*, Int32 *directionMode*)

Set the RTP callbacks to allow access to the sent and received RTP packets. The onRTPPacketCallback events will be triggered.

Parameters

<i>sessionId</i>	The session ID of call.
<i>mediaType</i>	0 -audio 1-video 2-screen.
<i>directionMode</i>	The RTP stream callback mode.
Type	Description
DIRECTION_SEND	Callback the send RTP stream for one channel based on the given sessionId.
DIRECTION_RECV	Callback the received RTP stream for one channel based on the given sessionId.
DIRECTION_SEND_RECV	Callback both local and remote RTWP stream on the given sessionId.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Audio and video codecs functions

Functions

- Int32 [PortSIP.PortSIPLib.addAudioCodec](#) ([AUDIOCODEC_TYPE](#) codecType)
Enable an audio codec. It will be appears in SDP.
- Int32 [PortSIP.PortSIPLib.addVideoCodec](#) ([VIDEOCODEC_TYPE](#) codecType)
Enable a video codec. It will appear in SDP.
- Boolean [PortSIP.PortSIPLib.isAudioCodecEmpty](#) ()
Detect if enabled audio codecs is empty or not.
- Boolean [PortSIP.PortSIPLib.isVideoCodecEmpty](#) ()
Detect if enabled video codecs is empty or not.
- Int32 [PortSIP.PortSIPLib.setAudioCodecPayloadType](#) ([AUDIOCODEC_TYPE](#) codecType, Int32 payloadType)
Set the RTP payload type for dynamic audio codec.
- Int32 [PortSIP.PortSIPLib.setVideoCodecPayloadType](#) ([VIDEOCODEC_TYPE](#) codecType, Int32 payloadType)
Set the RTP payload type for dynamic Video codec.
- void [PortSIP.PortSIPLib.clearAudioCodec](#) ()
Remove all enabled audio codecs.

- void [PortSIP.PortSIPLib.clearVideoCodec \(\)](#)
Remove all enabled video codecs.
 - Int32 [PortSIP.PortSIPLib.setAudioCodecParameter \(AUDIOCODEC_TYPE codecType, String parameter\)](#)
Set the codec parameter for audio codec.
 - Int32 [PortSIP.PortSIPLib.setVideoCodecParameter \(VIDEOCODEC_TYPE codecType, String parameter\)](#)
Set the codec parameter for video codec.
-

Detailed Description

Function Documentation

Int32 [PortSIP.PortSIPLib.addAudioCodec \(AUDIOCODEC_TYPE codecType\)](#)

Enable an audio codec. It will appear in SDP.

Parameters

<i>codecType</i>	Audio codec type.
------------------	-------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 [PortSIP.PortSIPLib.addVideoCodec \(VIDEOCODEC_TYPE codecType\)](#)

Enable a video codec. It will appear in SDP.

Parameters

<i>codecType</i>	Video codec type.
------------------	-------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Boolean [PortSIP.PortSIPLib.isAudioCodecEmpty \(\)](#)

Detect if enabled audio codecs is empty or not.

Returns

If no audio codec is enabled, it will return value true, otherwise false.

Boolean PortSIP.PortSIPLib.isVideoCodecEmpty ()

Detect if enabled video codecs is empty or not.

Returns

If no video codec is enabled, it will return value true, otherwise false.

Int32 PortSIP.PortSIPLib.setAudioCodecPayloadType ([AUDIOCODEC_TYPE](#) *codecType*, Int32 *payloadType*)

Set the RTP payload type for dynamic audio codec.

Parameters

<i>codecType</i>	Audio codec type, which is defined in the PortSIPTypes file.
<i>payloadType</i>	The new RTP payload type that you want to set.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return value a specific error code.

Int32 PortSIP.PortSIPLib.setVideoCodecPayloadType ([VIDEOCODEC_TYPE](#) *codecType*, Int32 *payloadType*)

Set the RTP payload type for dynamic Video codec.

Parameters

<i>codecType</i>	Video codec type, which is defined in the PortSIPTypes file.
<i>payloadType</i>	The new RTP payload type that you want to set.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setAudioCodecParameter ([AUDIOCODEC_TYPE](#) *codecType*, String *parameter*)

Set the codec parameter for audio codec.

Parameters

<i>codecType</i>	Audio codec type, defined in the PortSIPTypes file.
<i>parameter</i>	The parameter in string format.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

Example:

```
setAudioCodecParameter(AUDIOCODEC_AMR, "mode-set=0; octet-align=1;  
robust-sorting=0");
```

Int32 PortSIP.PortSIPLib.setVideoCodecParameter ([VIDEOCODEC_TYPE](#) codecType, String parameter)

Set the codec parameter for video codec.

Parameters

codecType	Video codec type, defined in the PortSIPTypes file.
parameter	The parameter in string format.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return value a specific error code.

Remarks

Example:

```
setVideoCodecParameter(VIDEO_CODEC_H264, "profile-level-id=420033;  
packetization-mode=0");
```

Additional setting functions

Functions

- Int32 [PortSIP.PortSIPLib.setSrtpPolicy](#) ([SRTP_POLICY](#) srtpPolicy, Boolean allowSrtpOverUnsecureTransport)
Set the SRTP policy.
- Int32 [PortSIP.PortSIPLib.setRtpPortRange](#) (Int32 minimumRtpPort, Int32 maximumRtpPort)
Set the RTP ports range for RTP streaming.
- Int32 [PortSIP.PortSIPLib.enableCallForward](#) (Boolean forBusyOnly, String forwardTo)
Enable call forward.
- Int32 [PortSIP.PortSIPLib.disableCallForward](#) ()
Disable the call forwarding. The SDK is not forwarding any incoming call after this function is called.
- Int32 [PortSIP.PortSIPLib.enableSessionTimer](#) (Int32 timerSeconds, [SESSION_REFRESH_MODE](#) refreshMode)
Allows to periodically refresh Session Initiation Protocol (SIP) sessions by sending INVITE requests repeatedly.
- Int32 [PortSIP.PortSIPLib.disableSessionTimer](#) ()
Disable the session timer.
- void [PortSIP.PortSIPLib.setDoNotDisturb](#) (Boolean state)
Enable the "Do not disturb" to enable/disable.
- Int32 [PortSIP.PortSIPLib.enableAutoCheckMwi](#) (Boolean state)
Allows to enable/disable the check MWI (Message Waiting Indication) automatically.

- Int32 [PortSIP.PortSIPLib.setRtpKeepAlive](#) (Boolean state, Int32 keepAlivePayloadType, Int32 deltaTransmitTimeMS)
Enable or disable to send RTP keep-alive packet when the call is established.
- Int32 [PortSIP.PortSIPLib.setKeepAliveTime](#) (Int32 keepAliveTime)
Enable or disable to send SIP keep-alive packet.
- Int32 [PortSIP.PortSIPLib.getSipMessageHeaderValue](#) (String sipMessage, String headerName, StringBuilder headerValue, Int32 headerValueLength)
Access the SIP header of SIP message.
- Int32 [PortSIP.PortSIPLib.addSipMessageHeader](#) (Int32 sessionId, String methodName, Int32 msgType, String headerName, String headerValue)
Add the SIP Message header into the specified outgoing SIP message.
- Int32 [PortSIP.PortSIPLib.removeAddedSipMessageHeader](#) (Int32 sipMessageHeaderId)
Remove the headers (custom header) added by addSipMessageHeader.
- Int32 [PortSIP.PortSIPLib.clearAddedSipMessageHeaders](#) ()
Clear the added extension headers (custom headers)
- Int32 [PortSIP.PortSIPLib.modifySipMessageHeader](#) (Int32 sessionId, String methodName, Int32 msgType, String headerName, String headerValue)
Modify the special SIP header value for every outgoing SIP message.
- Int32 [PortSIP.PortSIPLib.removeModifiedSipMessageHeader](#) (Int32 sipMessageHeaderId)
Remove the extension header (custom header) from every outgoing SIP message.
- Int32 [PortSIP.PortSIPLib.clearModifiedSipMessageHeaders](#) ()
Clear the modified headers value, and do not modify every outgoing SIP message header values any longer.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.setSrtpPolicy ([SRTP_POLICY](#) *srtppolicy*, Boolean *allowSrtpOverUnsecureTransport*)

Set the SRTP policy.

Parameters

<i>srtppolicy</i>	The SRTP policy.
-------------------	------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return value a specific error code.

Int32 PortSIP.PortSIPLib.setRtpPortRange (Int32 *minimumRtpPort*, Int32 *maximumRtpPort*)

Set the RTP ports range for RTP streaming.

Parameters

<i>minimumRtpPort</i>	The minimum RTP port.
<i>maximumRtpPort</i>	The maximum RTP port.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

The port range ((max - min) % maxCallLines) should be greater than 4.

Int32 PortSIP.PortSIPLib.enableCallForward (Boolean *forBusyOnly*, String *forwardTo*)

Enable call forward.

Parameters

<i>forBusyOnly</i>	If this parameter is set as true, the SDK will forward all incoming calls when currently it's busy. If it's set as false, the SDK forward all incoming calls anyway.
<i>forwardTo</i>	The call forward target. It must be like sip:xxxx@sip.portsip.com .

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.disableCallForward ()

Disable the call forwarding. The SDK is not forwarding any incoming call after this function is called.

Returns

If the function succeeds, it will return value 0. If the function fails, the return value is a specific error code.

Int32 PortSIP.PortSIPLib.enableSessionTimer (Int32 *timerSeconds*, SESSION_REFRESH_MODE *refreshMode*)

Allows to periodically refresh Session Initiation Protocol (SIP) sessions by sending INVITE requests repeatedly.

Parameters

<i>timerSeconds</i>	The value of the refreshment interval in seconds. Minimum value of 90 seconds required.
<i>refreshMode</i>	Allow to set the session refresh by UAC or UAS: SESSION_REFERESH_UAC or SESSION_REFERESH_UAS;

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

The repeated INVITE requests, or re-INVITES, are sent during an active call log to allow user agents (UA) or proxies to determine the status of a SIP session. Without this keepalive mechanism, proxies that remember incoming and outgoing requests (stateful proxies) may continue to retain call state in vain. If a UA fails to send a BYE message at the end of a session or if the BYE message is lost because of network problems, a stateful proxy will not know that the session has ended. The re-INVITES ensure that active sessions stay active and completed sessions are terminated.

Int32 PortSIP.PortSIPLib.disableSessionTimer ()

Disable the session timer.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

void PortSIP.PortSIPLib.setDoNotDisturb (Boolean state)

Enable the "Do not disturb" to enable/disable.

Parameters

<i>state</i>	If it is set to true, the SDK will reject all incoming calls anyway.
--------------	--

Int32 PortSIP.PortSIPLib.enableAutoCheckMwi (Boolean state)

Allows to enable/disable the check MWI (Message Waiting Indication) automatically.

Parameters

<i>state</i>	If it is set as true, MWI will be checked automatically once successfully registered to a SIP proxy server.
--------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setRtpKeepAlive (Boolean state, Int32 keepAlivePayloadType, Int32 deltaTransmitTimeMS)

Enable or disable to send RTP keep-alive packet when the call is established.

Parameters

<i>state</i>	Set to true to allow to send the keep-alive packet during the conversation.
<i>keepAlivePayloadType</i>	The payload type of the keep-alive RTP packet. It's usually set to 126.
<i>deltaTransmitTimeMS</i>	The keep-alive RTP packet sending interval, in millisecond. Recommend value ranges 15000 - 300000.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setKeepAliveTime (Int32 *keepAliveTime*)

Enable or disable to send SIP keep-alive packet.

Parameters

<i>keepAliveTime</i>	This is the SIP keep alive time interval in seconds. Set it to 0 to disable the SIP keep alive. Recommend to set as 30 or 50.
----------------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.getSipMessageHeaderValue (String *sipMessage*, String *headerName*, StringBuilder *headerValue*, Int32 *headerValueLength*)

Access the SIP header of SIP message.

Parameters

<i>sipMessage</i>	The SIP message.
<i>headerName</i>	The header which wishes to access the SIP message.
<i>headerValue</i>	The buffer to receive header value.
<i>headerValueLength</i>	The headerValue buffer size. Usually we recommend to set it more than 512 bytes.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

When receiving a SIP message in the onReceivedSignaling callback event, and wishes to get SIP message header value, please use `getSipMessageHeaderValue`:

```
StringBuilder value = new StringBuilder();
value.Length = 512;
getSipMessageHeaderValue(message, name, value);
```

Int32 PortSIP.PortSIPLib.addSipMessageHeader (Int32 *sessionId*, String *methodName*, Int32 *msgType*, String *headerName*, String *headerValue*)

Add the SIP Message header into the specified outgoing SIP message.

Parameters

<i>sessionId</i>	Add the header to the SIP message with the specified session Id only. By
------------------	--

	setting to -1, it will be added to all messages.
<i>methodName</i>	Just add the header to the SIP message with specified method name. For example: "INVITE", "REGISTER", "INFO" etc. If "ALL" specified, it will add all SIP messages.
<i>msgType</i>	1 refers to apply to the request message, 2 refers to apply to the response message, 3 refers to apply to both request and response.
<i>headerName</i>	The custom header name that will appear in every outgoing SIP message.
<i>headerValue</i>	The custom header value.

Returns

If the function succeeds, it will return addedSipMessageId, which is greater than 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.removeAddedSipMessageHeader (Int32 *sipMessageHeaderId*)

Remove the headers (custom header) added by addSipMessageHeader.

Parameters

<i>addedSipMessageId</i>	The addedSipMessageId return by addSipMessageHeader.
--------------------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.clearAddedSipMessageHeaders ()

Clear the added extension headers (custom headers)

Remarks

For example, we have added two custom headers into every outgoing SIP message and wish to remove them.

```
addExtensionHeader(-1, "ALL", 3, "Billing", "usd100.00");
addExtensionHeader(-1, "ALL", 3, "ServiceId", "8873456");
clearAddedSipMessageHeaders\(\);
```

Int32 PortSIP.PortSIPLib.modifySipMessageHeader (Int32 *sessionId*, String *methodName*, Int32 *msgType*, String *headerName*, String *headerValue*)

Modify the special SIP header value for every outgoing SIP message.

Parameters

<i>sessionId</i>	The header to the SIP message with the specified session Id. By setting to -1, it will be added to all messages.
<i>methodName</i>	Modify the header to the SIP message with specified method name only. For example: "INVITE", "REGISTER", "INFO" etc. If "ALL" specified, it will add all SIP messages.
<i>msgType</i>	1 refers to apply to the request message, 2 refers to apply to the response message, 3 refers to apply to both request and response.

Returns

If the function succeeds, it will return modifiedSipMessageId, which is greater than 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.removeModifiedSipMessageHeader (Int32 sipMessageHeaderId)

Remove the extension header (custom header) from every outgoing SIP message.

Parameters

modifiedSipMessageHeaderId	The modifiedSipMessageId is returned by modifySipMessageHeader.
----------------------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.clearModifiedSipMessageHeaders ()

Clear the modified headers value, and do not modify every outgoing SIP message header values any longer.

Remarks

For example, to modify two headers' value for every outgoing SIP message and wish to clear it:

```
modifySipMessageHeader(-1, "ALL", 3, "Expires", "1000");
modifySipMessageHeader(-1, "ALL", 3, "User-Agent", "MyTest Softphone 1.0");
clearModifiedSipMessageHeaders();
```

Audio and video functions

Functions

- Int32 [PortSIP.PortSIPLib.addSupportedMimeType](#) (String methodName, String mimeType, String subMimeType)
Set the SDK to receive the SIP messages that include special mime type.
- Int32 [PortSIP.PortSIPLib.setAudioSamples](#) (Int32 ptime, Int32 maxPtime)
Set the audio capture sample.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.addSupportedMimeType (String *methodName*, String *mimeType*, String *subMimeType*)

Set the SDK to receive the SIP messages that include special mime type.

Parameters

<i>methodName</i>	Method name of the SIP message, such as INVITE, OPTION, INFO, MESSAGE, UPDATE, ACK etc. For more details please read the RFC3261.
<i>mimeType</i>	The mime type of SIP message.
<i>subMimeType</i>	The sub mime type of SIP message.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

By default, [PortSIP](#) VoIP SDK supports these media types (mime types) below for incoming SIP messages:

```
"message/sipfrag" in NOTIFY message.  
"application/simple-message-summary" in NOTIFY message.  
"text/plain" in MESSAGE message.  
"application/dtmf-relay" in INFO message.  
"application/media_control+xml" in INFO message.
```

The SDK allows to receive SIP messages that include above mime types. Now if remote side send an INFO SIP message with its "Content-Type" header value "text/plain". SDK will reject this INFO message, as "text/plain" of INFO message is not included in the default support list. How should we enable the SDK to receive the SIP INFO message that includes "text/plain" mime type? The answer is addSupportedMimeType:

```
addSupportedMimeType ("INFO", "text", "plain");
```

If we want to receive the NOTIFY message with "application/media_control+xml", please:

```
addSupportedMimeType ("NOTIFY", "application", "media_control+xml");
```

For more details about the mime type, please visit this website:

<http://www.iana.org/assignments/media-types/>

Int32 PortSIP.PortSIPLib.setAudioSamples (Int32 *ptime*, Int32 *maxPtime*)

Set the audio capture sample.

Parameters

<i>ptime</i>	It should be a multiple of 10 between 10 - 60 (with 10 and 60 inclusive).
<i>maxPtime</i>	For the "maxptime" attribute, it should be a multiple of 10 between 10 - 60 (with 10 and 60 inclusive). It cannot be less than "ptime".

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

It will appear in the SDP of INVITE and 200 OK message as "ptime and "maxptime" attribute.

Access SIP message header functions

Functions

- Int32 [PortSIP.PortSIPLib.setAudioDeviceId](#) (Int32 recordingDeviceId, Int32 playoutDeviceId)
Set the audio device that will be used for audio call.
- Int32 [PortSIP.PortSIPLib.setVideoDeviceId](#) (Int32 deviceId)
Set the video device that will be used for video call.
- Int32 [PortSIP.PortSIPLib.setVideoResolution](#) (Int32 width, Int32 height)
Set the video capturing resolution.
- Int32 [PortSIP.PortSIPLib.setAudioBitrate](#) (Int32 sessionId, [AUDIOCODEC_TYPE](#) audioCodecType, Int32 bitrateKbps)
Set the audio bitrate.
- Int32 [PortSIP.PortSIPLib.setVideoBitrate](#) (Int32 sessionId, Int32 bitrateKbps)
Set the video bitrate.
- Int32 [PortSIP.PortSIPLib.setVideoFrameRate](#) (Int32 sessionId, Int32 frameRate)
Set the video frame rate.
- Int32 [PortSIP.PortSIPLib.sendVideo](#) (Int32 sessionId, Boolean sendState)
Send the video to remote side.
- void [PortSIP.PortSIPLib.muteMicrophone](#) (Boolean mute)
Mute the device microphone. It's unavailable for Android and iOS.
- void [PortSIP.PortSIPLib.muteSpeaker](#) (Boolean mute)
Mute the device speaker. It's unavailable for Android and iOS.
- void [PortSIP.PortSIPLib.setChannelOutputVolumeScaling](#) (Int32 sessionId, Int32 scaling)
- void [PortSIP.PortSIPLib.setChannelInputVolumeScaling](#) (Int32 sessionId, Int32 scaling)
- Int32 [PortSIP.PortSIPLib.setRemoteVideoWindow](#) (Int32 sessionId, IntPtr remoteVideoWindow)
Set the window for a session that is used to display the received remote video image.
- Int32 [PortSIP.PortSIPLib.displayLocalVideo](#) (Boolean state, Boolean mirror, IntPtr localVideoWindow)
Start/stop displaying the local video image.
- Int32 [PortSIP.PortSIPLib.setVideoNackStatus](#) (Boolean state)
Enable/disable the NACK feature (rfc6642) that helps to improve the video quality.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.setAudioDeviceId (Int32 *recordingDeviceId*, Int32 *playoutDeviceId*)

Set the audio device that will be used for audio call.

Parameters

<i>recordingDeviceId</i>	Device ID (index) for audio recording. (Microphone).
<i>playoutDeviceId</i>	Device ID (index) for audio playback (Speaker).

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setVideoDeviceId (Int32 *deviceId*)

Set the video device that will be used for video call.

Parameters

<i>deviceId</i>	Device ID (index) for video device (camera).
-----------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setVideoResolution (Int32 *width*, Int32 *height*)

Set the video capturing resolution.

Parameters

<i>width</i>	Video width.
<i>height</i>	Video height.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setAudioBitrate (Int32 *sessionId*, [AUDIOCODEC_TYPE](#) *audioCodecType*, Int32 *bitrateKbps*)

Set the audio bitrate.

Parameters

<i>bitrateKbps</i>	The audio bitrate in KBPS.
--------------------	----------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setVideoBitrate (Int32 sessionId, Int32 bitrateKbps)

Set the video bitrate.

Parameters

<i>bitrateKbps</i>	The video bitrate in KBPS.
--------------------	----------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setVideoFrameRate (Int32 sessionId, Int32 frameRate)

Set the video frame rate.

Parameters

<i>frameRate</i>	The frame rate value with minimum value 5, and maximum value 30. A greater value will enable you better video quality but requires more bandwidth.
------------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

Usually you do not need to call this function to set the frame rate. The SDK uses default frame rate.

Int32 PortSIP.PortSIPLib.sendVideo (Int32 sessionId, Boolean sendState)

Send the video to remote side.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>sendState</i>	Set to true to send the video, or false to stop sending.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

void PortSIP.PortSIPLib.muteMicrophone (Boolean mute)

Mute the device microphone. It's unavailable for Android and iOS.

Parameters

<i>mute</i>	If the value is set to true, the microphone will be muted. You may also set it to false to un-mute it.
-------------	--

void PortSIP.PortSIPLib.muteSpeaker (Boolean *mute*)

Mute the device speaker. It's unavailable for Android and iOS.

Parameters

<i>mute</i>	If the value is set to true, the speaker is muted. You may also set it to false to un-mute it.
-------------	--

void PortSIP.PortSIPLib.setChannelOutputVolumeScaling (Int32 *sessionId*, Int32 *scaling*)

Set a volume |scaling| to be applied to the outgoing signal of a specific audio channel.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>scaling</i>	Valid scale ranges [0, 1000]. Default is 100.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

void PortSIP.PortSIPLib.setChannelInputVolumeScaling (Int32 *sessionId*, Int32 *scaling*)

Set a volume |scaling| to be applied to the microphone signal of a specific audio channel.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>scaling</i>	Valid scale ranges [0, 1000]. Default is 100.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setRemoteVideoWindow (Int32 *sessionId*, IntPtr *remoteVideoWindow*)

Set the window for a session that is used to display the received remote video image.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>remoteVideoWindow</i>	The window to display received remote video image.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.displayLocalVideo (Boolean *state*, Boolean *mirror*, IntPtr *localVideoWindow*)

Start/stop displaying the local video image.

Parameters

<i>state</i>	Set to true to display local video image.
--------------	---

<i>mirror</i>	Set to true to display the mirror image of local video.
<i>localVideoWindow</i>	The window on which the local video image from camera will be displayed.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setVideoNackStatus (Boolean state)

Enable/disable the NACK feature (rfc6642) that helps to improve the video quality.

Parameters

<i>state</i>	Set to true to enable.
--------------	------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Call functions

Functions

- Int32 [PortSIP.PortSIPLib.call](#) (String callee, Boolean sendSdp, Boolean videoCall)
Make a call.
- Int32 [PortSIP.PortSIPLib.rejectCall](#) (Int32 sessionId, int code)
rejectCall Reject the incoming call.
- Int32 [PortSIP.PortSIPLib.hangUp](#) (Int32 sessionId)
hangUp Hang up the call.
- Int32 [PortSIP.PortSIPLib.answerCall](#) (Int32 sessionId, Boolean videoCall)
answerCall Answer the incoming call.
- Int32 [PortSIP.PortSIPLib.updateCall](#) (Int32 sessionId, bool enableAudio, bool enableVideo)
Use the re-INVITE to update the established call.
- Int32 [PortSIP.PortSIPLib.hold](#) (Int32 sessionId)
To place a call on hold.
- Int32 [PortSIP.PortSIPLib.unHold](#) (Int32 sessionId)
Take off hold.
- Int32 [PortSIP.PortSIPLib.muteSession](#) (Int32 sessionId, Boolean muteIncomingAudio, Boolean muteOutgoingAudio, Boolean muteIncomingVideo, Boolean muteOutgoingVideo)
Mute the specified session audio or video.
- Int32 [PortSIP.PortSIPLib.forwardCall](#) (Int32 sessionId, String forwardTo)
Forward call to another one when receiving the incoming call.

- Int32 [PortSIP.PortSIPLib.pickupBLFCall](#) (String replaceDialogId, Boolean videoCall)
This function will be used for picking up a call based on the BLF (Busy Lamp Field) status.
 - Int32 [PortSIP.PortSIPLib.sendDtmf](#) (Int32 sessionId, [DTMF_METHOD](#) dtmfMethod, int code, int dtmfDuration, bool playDtmfTone)
Send DTMF tone.
-

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.call (String callee, Boolean sendSdp, Boolean videoCall)

Make a call.

Parameters

<i>callee</i>	The callee. It can be either name or full SIP URI. For example: user001, sip: user001@sip.iptel.org or sip: user002@sip.yourdomain.com :5068
<i>sendSdp</i>	If it's set to false, the outgoing call doesn't include the SDP in INVITE message.
<i>videoCall</i>	If it's set to true with at least one video codecs added, the outgoing call will include the video codec into SDP.

Returns

If the function succeeds, it will return the session ID of the call that is greater than 0. If the function fails, it will return a specific error code. Note: the function success just means the outgoing call is being processed. You need to detect the call final state in onInviteTrying, onInviteRinging, onInviteFailure callback events.

Int32 PortSIP.PortSIPLib.rejectCall (Int32 sessionId, int code)

rejectCall Reject the incoming call.

Parameters

<i>sessionId</i>	The sessionId of the call.
<i>code</i>	Reject code. For example, 486, 480 etc.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.hangUp (Int32 sessionId)

hangUp Hang up the call.

Parameters

<i>sessionId</i>	Session ID of the call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.answerCall (Int32 sessionId, Boolean videoCall)

answerCall Answer the incoming call.

Parameters

<i>sessionId</i>	The session ID of call.
<i>videoCall</i>	If the incoming call is a video call and the video codec is matched, set it to true to answer the video call. If it's set to false, the answered call will not include video codec answer anyway.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.updateCall (Int32 sessionId, bool enableAudio, bool enableVideo)

Use the re-INVITE to update the established call.

Parameters

<i>sessionId</i>	The session ID of call.
<i>enableAudio</i>	Set to true to allow the audio in updated call, or false to disable audio in updated call.
<i>enableVideo</i>	Set to true to allow the video in updated call, or false to disable video in updated call.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return value a specific error code.

Remarks

Example usage:

Example 1: A called B with the audio only, B answered A, there has an audio conversation between A, B. Now A wants to see B visually, A could use these functions to do it.

```
clearVideoCodec();  
addVideoCodec(VIDEOCODEC_H264);  
updateCall(sessionId, true, true);
```

Example 2: Remove video stream from current conversation.

```
updateCall(sessionId, true, false);
```

Int32 PortSIP.PortSIPLib.hold (Int32 sessionId)

To place a call on hold.

Parameters

<i>sessionId</i>	The session ID of call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.unHold (Int32 sessionId)

Take off hold.

Parameters

<i>sessionId</i>	The session ID of call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.muteSession (Int32 sessionId, Boolean muteIncomingAudio, Boolean muteOutgoingAudio, Boolean muteIncomingVideo, Boolean muteOutgoingVideo)

Mute the specified session audio or video.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>muteIncomingAudio</i>	Set it to true to mute incoming audio stream, and remote side audio cannot be heard.
<i>muteOutgoingAudio</i>	Set it to true to mute outgoing audio stream, and the remote side can't hear the audio.
<i>muteIncomingVideo</i>	Set it to true to mute incoming video stream, and the remote side video will be invisible.
<i>muteOutgoingVideo</i>	Set it to true to mute outgoing video stream, and the remote side can't see the video.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.forwardCall (Int32 sessionId, String forwardTo)

Forward call to another one when receiving the incoming call.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>forwardTo</i>	Target of the forwarding. It can be "sip:number@sipserver.com" or "number" only.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return value a specific error code.

Int32 PortSIP.PortSIPLib.pickupBLFCall (String replaceDialogId, Boolean videoCall)

This function will be used for picking up a call based on the BLF (Busy Lamp Field) status.

Parameters

<i>replaceDialogId</i>	The session ID of the call.
<i>videoCall</i>	Target of the forwarding. It can be "sip:number@sipserver.com" or "number" only.

Returns

If the function succeeds, it will return a session ID that is greater than 0 to the new call, otherwise returns a specific error code that is less than 0.

Remarks

The scenario is:

1. User 101 subscribed the user 100's call status: sendSubscription(mSipLib, "100", "dialog");
2. When 100 hold a call or 100 is ringing, onDialogStateUpdated callback will be triggered, and 101 will receive this callback. Now 101 can use pickupBLFCall function to pick the call rather than 100 to talk with caller.

Int32 PortSIP.PortSIPLib.sendDtmf (Int32 sessionId, [DTMF METHOD](#) dtmfMethod, int code, int dtmfDuration, bool playDtmfTone)

Send DTMF tone.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>dtmfMethod</i>	DTMF tone could be sent with two methods: DTMF_RFC2833 and DTMF_INFO, of which DTMF_RFC2833 is recommend.
<i>code</i>	The DTMF tone (0-16).

<i>code</i>	Description
0	The DTMF tone 0.
1	The DTMF tone 1.
2	The DTMF tone 2.
3	The DTMF tone 3.
4	The DTMF tone 4.
5	The DTMF tone 5.
6	The DTMF tone 6.
7	The DTMF tone 7.
8	The DTMF tone 8.
9	The DTMF tone 9.
10	The DTMF tone *.
11	The DTMF tone #.
12	The DTMF tone A.
13	The DTMF tone B.
14	The DTMF tone C.
15	The DTMF tone D.
16	The DTMF tone FLASH.

Parameters

<i>dtmfDuration</i>	The DTMF tone samples. Recommended value 160.
<i>playDtmfTone</i>	If it is set to true, the SDK plays local DTMF tone sound when sending DTMF.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Refer functions

Functions

- Int32 [PortSIP.PortSIPLib.refer](#) (Int32 sessionId, String referTo)
Refer the current call to another one.
- Int32 [PortSIP.PortSIPLib.attendedRefer](#) (Int32 sessionId, Int32 replaceSessionId, String referTo)
- Int32 [PortSIP.PortSIPLib.attendedRefer2](#) (IntPtr libSDK, Int32 sessionId, Int32 replaceSessionId, String replaceMethod, String target, String referTo)
Make an attended refer with specified request line and specified method embedded into the "Refer-To" header.
- Int32 [PortSIP.PortSIPLib.outOfDialogRefer](#) (Int32 replaceSessionId, String replaceMethod, String target, String referTo)
Send an out of dialog REFER to replace the specified call.
- Int32 [PortSIP.PortSIPLib.acceptRefer](#) (Int32 referId, String referSignalingMessage)
Accept the REFER request, and a new call will be made if called this function. The function is usually called after onReceivedRefer callback event.
- Int32 [PortSIP.PortSIPLib.rejectRefer](#) (Int32 referId)
Reject the REFER request.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.refer (Int32 sessionId, String referTo)

Refer the current call to another one.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>referTo</i>	Target of the refer, which can be either "sip:number@sipserver.com" or "number".

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

```
refer(sessionId, "sip:testuser12@sip.portsip.com");
```

You can watch the video on YouTube at https://www.youtube.com/watch?v=_2w9EGgr3FY. It will demonstrate the transfer.

Int32 PortSIP.PortSIPLib.attendedRefer (Int32 sessionId, Int32 replaceSessionId, String referTo)

```
@brief Make an attended refer.

@param sessionId      The session ID of the call.
@param replaceSessionId Session ID of the repferred call.
@param referTo        Target of the refer, which can be either
"sip:number@sipserver.com" or "number".

@return If the function succeeds, it will return value 0. If the function fails,
it will return a specific error code.
@remark
Please read the sample project source code for more details, or you can watch
the video on YouTube at https://www.youtube.com/watch?v=NezhIZW4lV4,
```

which will demonstrate the transfer.

Int32 PortSIP.PortSIPLib.attendedRefer2 (IntPtr libSDK, Int32 sessionId, Int32 replaceSessionId, String replaceMethod, String target, String referTo)

Make an attended refer with specified request line and specified method embedded into the "Refer-To" header.

Parameters

<i>sessionId</i>	Session ID of the call.
<i>replaceSessionId</i>	Session ID of the replaced call.
<i>replaceMethod</i>	The SIP method name which will be embeded in the "Refer-To" header, usually INVITE or BYE.
<i>target</i>	The target to which the REFER message will be sent. It appears in the "Request Line" of REFER message.
<i>referTo</i>	Target of the refer that appears in the "Refer-To" header. It can be either "sip:number@sipserver.com" or "number".

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

Please read the sample project source code for more details, or you can watch the video on YouTube at <https://www.youtube.com/watch?v=NezhIZW4lV4>, which will demonstrate the transfer.

Int32 PortSIP.PortSIPLib.outOfDialogRefer (Int32 replaceSessionId, String replaceMethod, String target, String referTo)

Send an out of dialog REFER to replace the specified call.

Parameters

<i>replaceSessionId</i>	The session ID of the session which will be replaced.
<i>replaceMethod</i>	The SIP method name which will be added in the "Refer-To" header, usually INVITE or BYE.
<i>target</i>	The target to which the REFER message will be sent.
<i>referTo</i>	The URI to be added into the "Refer-To" header.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.acceptRefer (Int32 referId, String referSignalingMessage)

Accept the REFER request, and a new call will be made if called this function. The function is usually called after onReceivedRefer callback event.

Parameters

<i>referId</i>	The ID of REFER request that comes from onReceivedRefer callback event.
<i>referSignalingMessage</i>	The SIP message of REFER request that comes from onReceivedRefer callback event.

Returns

If the function succeeds, it will return a session ID greater than 0 to the new call for REFER; otherwise a specific error code less than 0.

Int32 PortSIP.PortSIPLib.rejectRefer (Int32 referId)

Reject the REFER request.

Parameters

<i>referId</i>	The ID of REFER request that comes from onReceivedRefer callback event.
----------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Send audio and video stream functions

Functions

- Int32 [PortSIP.PortSIPLib.enableSendPcmStreamToRemote](#) (Int32 sessionId, Boolean state, Int32 streamSamplesPerSec)
Enable the SDK to send PCM stream data to remote side from another source instead of microphone.

- Int32 [PortSIP.PortSIPLib.sendPcmStreamToRemote](#) (Int32 sessionId, byte[] data, Int32 dataLength)
Send the audio stream in PCM format from another source instead of audio device capturing (microphone).
 - Int32 [PortSIP.PortSIPLib.enableSendVideoStreamToRemote](#) (Int32 sessionId, Boolean state)
Enable the SDK send video stream data to remote side from another source instead of camera.
 - Int32 [PortSIP.PortSIPLib.sendVideoStreamToRemote](#) (Int32 sessionId, byte[] data, Int32 dataLength, Int32 width, Int32 height)
Send the video stream to remote side.
-

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.enableSendPcmStreamToRemote (Int32 sessionId, Boolean state, Int32 streamSamplesPerSec)

Enable the SDK to send PCM stream data to remote side from another source instead of microphone.

Parameters

<i>sessionId</i>	The session ID of call.
<i>state</i>	Set to true to enable the send stream, or false to disable.
<i>streamSamplesPer Sec</i>	The PCM stream data sample in seconds. For example: 8000 or 16000.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

This function MUST be called first to send the PCM stream data to another side.

Int32 PortSIP.PortSIPLib.sendPcmStreamToRemote (Int32 sessionId, byte[] data, Int32 dataLength)

Send the audio stream in PCM format from another source instead of audio device capturing (microphone).

Parameters

<i>sessionId</i>	Session ID of the call conversation.
<i>data</i>	The PCM audio stream data. It must be 16bit, mono.
<i>dataLength</i>	The size of data.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

Usually it should be used as below:

```
enableSendPcmStreamToRemote(sessionId, true, 16000);
sendPcmStreamToRemote(sessionId, data, dataSize);
```

You can't have too much audio data at one time as we have 100ms audio buffer only. Once you put too much, data will be lost. It is recommended to send 20ms audio data every 20ms.

Int32 PortSIP.PortSIPLib.enableSendVideoStreamToRemote (Int32 sessionId, Boolean state)

Enable the SDK send video stream data to remote side from another source instead of camera.

Parameters

<i>sessionId</i>	The session ID of call.
<i>state</i>	Set to true to enable the sending stream, or false to disable.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.sendVideoStreamToRemote (Int32 sessionId, byte[] data, Int32 dataLength, Int32 width, Int32 height)

Send the video stream to remote side.

Parameters

<i>sessionId</i>	Session ID of the call conversation.
<i>data</i>	The video stream data. It must be in i420 format.
<i>dataLength</i>	The size of data.
<i>width</i>	The video image width.
<i>height</i>	The video image height.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

Send the video stream in i420 from another source instead of video device capturing (camera).

Before calling this function, you MUST call the enableSendVideoStreamToRemote function.

Usually it should be used as below:

```
enableSendVideoStreamToRemote(sessionId, true);
sendVideoStreamToRemote(sessionId, data, dataSize, 352, 288);
```

RTP packets, Audio stream and video stream callback functions

Functions

- Int32 [PortSIP.PortSIPLib.enableAudioStreamCallback](#) (Int32 callbackObject, Int32 sessionId, Boolean enable, [DIRECTION_MODE](#) direction)
Enable/disable the audio stream callback.
 - Int32 [PortSIP.PortSIPLib.enableVideoStreamCallback](#) (Int32 callbackObject, Int32 sessionId, [DIRECTION_MODE](#) direction)
Enable/disable the video stream callback.
-

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.enableAudioStreamCallback (Int32 *callbackObject*, Int32 *sessionId*, Boolean *enable*, [DIRECTION_MODE](#) *direction*)

Enable/disable the audio stream callback.

Parameters

<i>callbackObject</i>	The callback object that you passed in can be accessed once callback function triggered.
<i>sessionId</i>	The session ID of call.
<i>enable</i>	Set to true to enable audio stream callback, or false to stop the callback.
<i>direction</i>	The audio stream callback direction.
Type	Description
DIRECTION_SEND	Callback the send audio stream for one channel based on the given sessionId.
DIRECTION_RECV	Callback the received audio stream for one channel based on the given sessionId.
DIRECTION_SEND_RECV	Callback both send & received audio stream for one channel based on the given sessionId.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

The onAudioRawCallback event will be triggered if the callback is enabled.

Int32 PortSIP.PortSIPLib.enableVideoStreamCallback (Int32 *callbackObject*, Int32 *sessionId*, [DIRECTION_MODE](#) *direction*)

Enable/disable the video stream callback.

Parameters

<i>callbackObject</i>	The callback object that you passed in can be accessed once callback function triggered.
<i>sessionId</i>	The session ID of call.
<i>direction</i>	The video stream callback direction.

Type	Description
DIRECTION_SEND	Callback the send video stream for one channel based on the given sessionId.
DIRECTION_RECV	Callback the received video stream for one channel based on the given sessionId.
DIRECTION_SEND_RECV	Callback both send & received video stream for one channel based on the given sessionId.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

The onVideoRawCallback event will be triggered if the callback is enabled.

Record functions

Functions

- Int32 [PortSIP.PortSIPLib.startRecord](#) (Int32 sessionId, String recordFilePath, String recordFileName, Boolean appendTimestamp, [AUDIO_RECORDING_FILEFORMAT](#) audioFileFormat, [RECORD_MODE](#) audioRecordMode, [VIDEOCODEC_TYPE](#) videoFileCodecType, [RECORD_MODE](#) videoRecordMode)
Start recording the call.
- Int32 [PortSIP.PortSIPLib.stopRecord](#) (Int32 sessionId)
Stop record.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.startRecord (Int32 sessionId, String recordFilePath, String recordFileName, Boolean appendTimestamp, [AUDIO RECORDING FILEFORMAT](#), [audioFileFormat](#), [RECORD MODE](#) audioRecordMode, [VIDEOCODEC TYPE](#) videoCodecType, [RECORD MODE](#) videoRecordMode)

Start recording the call.

Parameters

<i>sessionId</i>	The session ID of call conversation.
<i>recordFilePath</i>	The file path to which the record file will be saved. It must be existent.
<i>recordFileName</i>	The file name of record file. For example: audiorecord.wav or videorecord.avi.
<i>appendTimestamp</i>	Set to true to append the timestamp to the recording file name.
<i>audioFileFormat</i>	The audio record file format.
<i>audioRecordMode</i>	The audio record mode.
<i>videoCodecType</i>	The codec which is used for compressing the video data to save into video record file.
<i>videoRecordMode</i>	Allow to set video record mode, with record received and/or sent supported.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.stopRecord (Int32 sessionId)

Stop record.

Parameters

<i>sessionId</i>	The session ID of call conversation.
------------------	--------------------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Play audio and video file to remote functions

Functions

- Int32 [PortSIP.PortSIPLib.playVideoFileToRemote](#) (Int32 sessionId, String fileName, Boolean loop, Boolean playAudio)
Play an AVI file to remote party.
- Int32 [PortSIP.PortSIPLib.stopPlayVideoFileToRemote](#) (Int32 sessionId)
Stop playing video file to remote side.
- Int32 [PortSIP.PortSIPLib.playAudioFileToRemote](#) (Int32 sessionId, String fileName, Int32 fileSamplesPerSec, Boolean loop)
Play a wave file to remote party.

- Int32 [PortSIP.PortSIPLib.stopPlayAudioFileToRemote](#) (Int32 sessionId)
Stop playing wave file to remote side.
 - Int32 [PortSIP.PortSIPLib.playAudioFileToRemoteAsBackground](#) (Int32 sessionId, String fileName, Int32 fileSamplesPerSec)
Play a wave file to remote party as conversation background sound.
 - Int32 [PortSIP.PortSIPLib.stopPlayAudioFileToRemoteAsBackground](#) (Int32 sessionId)
Stop playing wave file to remote party as conversation background sound.
-

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.playVideoFileToRemote (Int32 sessionId, String fileName, Boolean loop, Boolean playAudio)

Play an AVI file to remote party.

Parameters

<i>sessionId</i>	Session ID of the call.
<i>fileName</i>	The full file path, such as "c:\\test.avi".
<i>loop</i>	Set to false to stop playing video file when it is ended, or true to play it repeatedly.
<i>playAudio</i>	If it's set to true, audio and video will be played together; if false, only video will be played.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.stopPlayVideoFileToRemote (Int32 sessionId)

Stop playing video file to remote side.

Parameters

<i>sessionId</i>	Session ID of the call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.playAudioFileToRemote (Int32 sessionId, String fileName, Int32 fileSamplesPerSec, Boolean loop)

Play a wave file to remote party.

Parameters

<i>sessionId</i>	Session ID of the call.
<i>fileName</i>	The full filepath, such as "c:\\test.wav".
<i>fileSamplesPerSec</i>	The wave file sample in seconds. It should be 8000, 16000 or 32000.
<i>loop</i>	Set to false to stop playing audio file when it is ended, or true to play it repeatedly.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.stopPlayAudioFileToRemote (Int32 sessionId)

Stop playing wave file to remote side.

Parameters

<i>sessionId</i>	Session ID of the call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.playAudioFileToRemoteAsBackground (Int32 sessionId, String fileName, Int32 fileSamplesPerSec)

Play a wave file to remote party as conversation background sound.

Parameters

<i>sessionId</i>	Session ID of the call.
<i>fileName</i>	The full filepath, such as "c:\\test.wav".
<i>fileSamplesPerSec</i>	The wave file sample in seconds. It should be 8000, 16000 or 32000.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.stopPlayAudioFileToRemoteAsBackground (Int32 sessionId)

Stop playing wave file to remote party as conversation background sound.

Parameters

<i>sessionId</i>	Session ID of the call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Conference functions

Functions

- Int32 [PortSIP.PortSIPLib.createAudioConference \(\)](#)
Create an audio conference. It will be failed if the existent conference is not ended yet.
- Int32 [PortSIP.PortSIPLib.createVideoConference \(IntPtr conferenceVideoWindow, Int32 width, Int32 height, Boolean displayLocalVideoInConference\)](#)
Create a video conference. It will be failed if the existent conference is not ended yet.
- void [PortSIP.PortSIPLib.destroyConference \(\)](#)
End the existent conference.
- Int32 [PortSIP.PortSIPLib.setConferenceVideoWindow \(IntPtr videoWindow\)](#)
Set the window for a conference that is used to display the received remote video image.
- Int32 [PortSIP.PortSIPLib.joinToConference \(Int32 sessionId\)](#)
Join a session into existent conference. If the call is in hold, it will be un-hold automatically.
- Int32 [PortSIP.PortSIPLib.removeFromConference \(Int32 sessionId\)](#)
Remove a session from an existent conference.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.createAudioConference ()

Create an audio conference. It will be failed if the existent conference is not ended yet.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.createVideoConference (IntPtr conferenceVideoWindow, Int32 width, Int32 height, Boolean displayLocalVideoInConference)

Create a video conference. It will be failed if the existent conference is not ended yet.

Parameters

<i>conferenceVideoW</i>	The UIView used to display the conference video.
-------------------------	--

<i>inwindow</i>	
<i>videoResolution</i>	The conference video resolution.
<i>displayLocalVideo</i>	Display the local video on video window or not.
<i>InConference</i>	

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

void PortSIP.PortSIPLib.destroyConference ()

End the existent conference.

Int32 PortSIP.PortSIPLib.setConferenceVideoWindow (IntPtr *videoWindow*)

Set the window for a conference that is used to display the received remote video image.

Parameters

<i>videoWindow</i>	The UIImageView used to display the conference video.
--------------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.joinToConference (Int32 *sessionId*)

Join a session into existent conference. If the call is in hold, it will be un-hold automatically.

Parameters

<i>sessionId</i>	Session ID of the call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.removeFromConference (Int32 *sessionId*)

Remove a session from an existent conference.

Parameters

<i>sessionId</i>	Session ID of the call.
------------------	-------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

RTP and RTCP QOS functions

Functions

- Int32 [PortSIP.PortSIPLib.setAudioRtcpBandwidth](#) (Int32 sessionId, Int32 BitsRR, Int32 BitsRS, Int32 KBitsAS)
Set the audio RTCP bandwidth parameters to the RFC3556.
 - Int32 [PortSIP.PortSIPLib.setVideoRtcpBandwidth](#) (Int32 sessionId, Int32 BitsRR, Int32 BitsRS, Int32 KBitsAS)
Set the video RTCP bandwidth parameters as the RFC3556.
-

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.setAudioRtcpBandwidth (Int32 sessionId, Int32 BitsRR, Int32 BitsRS, Int32 KBitsAS)

Set the audio RTCP bandwidth parameters to the RFC3556.

Parameters

<i>sessionId</i>	The session ID of call conversation.
<i>BitsRR</i>	The bits for the RR parameter.
<i>BitsRS</i>	The bits for the RS parameter.
<i>KBitsAS</i>	The Kbits for the AS parameter.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setVideoRtcpBandwidth (Int32 sessionId, Int32 BitsRR, Int32 BitsRS, Int32 KBitsAS)

Set the video RTCP bandwidth parameters as the RFC3556.

Parameters

<i>sessionId</i>	The session ID of call conversation.
<i>BitsRR</i>	The bits for the RR parameter.
<i>BitsRS</i>	The bits for the RS parameter.
<i>KBitsAS</i>	The Kbits for the AS parameter.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

RTP statistics functions

Functions

- Int32 [PortSIP.PortSIPLib.getAudioStatistics](#) (Int32 sessionId, out Int32 sendBytes, out Int32 sendPackets, out Int32 sendPacketsLost, out Int32 sendFractionLost, out Int32 sendRttMS, out Int32 sendCodecType, out Int32 sendJitterMS, out Int32 sendAudioLevel, out Int32 recvBytes, out Int32 recvPackets, out Int32 recvPacketsLost, out Int32 recvFractionLost, out Int32 recvCodecType, out Int32 recvJitterMS, out Int32 recvAudioLevel)
Obtain the statistics of audio channel.
- Int32 [PortSIP.PortSIPLib.getVideoStatistics](#) (Int32 sessionId, out Int32 sendBytes, out Int32 sendPackets, out Int32 sendPacketsLost, out Int32 sendFractionLost, out Int32 sendRttMS, out Int32 sendCodecType, out Int32 sendFrameWidth, out Int32 sendFrameHeight, out Int32 sendBitrateBPS, out Int32 sendFramerate, out Int32 recvBytes, out Int32 recvPackets, out Int32 recvPacketsLost, out Int32 recvFractionLost, out Int32 recvCodecType, out Int32 recvFrameWidth, out Int32 recvFrameHeight, out Int32 recvBitrateBPS, out Int32 recvFramerate)
Obtain the RTP statistics of video.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.getAudioStatistics (Int32 sessionId, out Int32 sendBytes, out Int32 sendPackets, out Int32 sendPacketsLost, out Int32 sendFractionLost, out Int32 sendRttMS, out Int32 sendCodecType, out Int32 sendJitterMS, out Int32 sendAudioLevel, out Int32 recvBytes, out Int32 recvPackets, out Int32 recvPacketsLost, out Int32 recvFractionLost, out Int32 recvCodecType, out Int32 recvJitterMS, out Int32 recvAudioLevel)

Obtain the statistics of audio channel.

Parameters

<i>sessionId</i>	The session ID of call conversation.
<i>sendBytes</i>	The number of sent bytes.
<i>sendPackets</i>	The number of sent packets.
<i>sendPacketsLost</i>	The number of sent but lost packets.
<i>sendFractionLost</i>	Fraction of sent but lost packets in percentage.
<i>sendRttMS</i>	The round-trip time of the session, in milliseconds.
<i>sendCodecType</i>	The sent Audio codec Type.
<i>sendJitterMS</i>	The sent jitter, in milliseconds.
<i>sendAudioLevel</i>	The sent audio level. It ranges 0 - 9.
<i>recvBytes</i>	The number of received bytes.
<i>recvPackets</i>	The number of received packets.
<i>recvPacketsLost</i>	The number of received but lost packet.
<i>recvFractionLost</i>	Fraction of received but lost packet in percentage.
<i>recvCodecType</i>	Received Audio codec Type.

<code>recvJitterMS</code>	The received jitter, in milliseconds.
<code>recvAudioLevel</code>	The received audio level. It ranges 0 - 9.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

```
Int32 PortSIP.PortSIPLib.getVideoStatistics (Int32 sessionId, out Int32 sendBytes,
out Int32 sendPackets, out Int32 sendPacketsLost, out Int32 sendFractionLost, out
Int32 sendRttMS, out Int32 sendCodecType, out Int32 sendFrameWidth, out Int32
sendFrameHeight, out Int32 sendBitrateBPS, out Int32 sendFramerate, out Int32
recvBytes, out Int32 recvPackets, out Int32 recvPacketsLost, out Int32
recvFractionLost, out Int32 recvCodecType, out Int32 recvFrameWidth, out Int32
recvFrameHeight, out Int32 recvBitrateBPS, out Int32 recvFramerate)
```

Obtain the RTP statistics of video.

Parameters

<code>sessionId</code>	The session ID of call conversation.
<code>sendBytes</code>	The number of sent bytes.
<code>sendPackets</code>	The number of sent packets.
<code>sendPacketsLost</code>	The number of sent but lost packets.
<code>sendFractionLost</code>	Fraction of sent but lost packets in percentage.
<code>sendRttMS</code>	The round-trip time of the session, in milliseconds.
<code>sendCodecType</code>	The sent Video codec type.
<code>sendFrameWidth</code>	Frame width for the sent video.
<code>sendFrameHeight</code>	Frame height for the sent video.
<code>sendBitrateBPS</code>	Bitrate in BPS for the sent video.
<code>sendFramerate</code>	Frame rate for the sent video.
<code>recvBytes</code>	The number of received bytes.
<code>recvPackets</code>	The number of received packets.
<code>recvPacketsLost</code>	The number of received but lost packet.
<code>recvFractionLost</code>	Fraction of received but lost packet in percentage.
<code>recvCodecType</code>	Received Video codec type.
<code>recvFrameWidth</code>	Frame width for the received video.
<code>recvFrameHeight</code>	Frame height for the received video.
<code>recvBitrateBPS</code>	(This parameter is not implemented yet) Bitrate in BPS for the received video.
<code>recvFramerate</code>	Framerate for the received video.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Audio effect functions

Functions

- void [PortSIP.PortSIPLib.enableVAD](#) (Boolean state)
Enable/disable Voice Activity Detection (VAD).

- void [PortSIP.PortSIPLib.enableAEC](#) (Boolean state)
Enable/disable AEC (Acoustic Echo Cancellation).

- `void PortSIP.PortSIPLib.enableCNG` (Boolean state)
Enable/disable Comfort Noise Generator (CNG).
 - `void PortSIP.PortSIPLib.enableAGC` (Boolean state)
Enable/disable Automatic Gain Control (AGC).
 - `void PortSIP.PortSIPLib.enableANS` (Boolean state)
Enable/disable Audio Noise Suppression (ANS).
 - Int32 `PortSIP.PortSIPLib.enableAudioQos` (Boolean state)
Set the DSCP (differentiated services code point) value of QoS (Quality of Service) for audio channel.
 - Int32 `PortSIP.PortSIPLib.enableVideoQos` (Boolean state)
Set the DSCP (differentiated services code point) value of QoS (Quality of Service) for video channel.
 - Int32 `PortSIP.PortSIPLib.setVideoMTU` (Int32 mtu)
Set the MTU size for video RTP packet.
-

Detailed Description

Function Documentation

void PortSIP.PortSIPLib.enableVAD (Boolean state)

Enable/disable Voice Activity Detection (VAD).

Parameters

<code>state</code>	Set to true to enable VAD, or false to disable.
--------------------	---

void PortSIP.PortSIPLib.enableAEC (Boolean state)

Enable/disable AEC (Acoustic Echo Cancellation).

Parameters

<code>state</code>	Set it to true to enable AEC, or false to disable.
--------------------	--

void PortSIP.PortSIPLib.enableCNG (Boolean state)

Enable/disable Comfort Noise Generator (CNG).

Parameters

<i>state</i>	Set it to true to enable CNG, or false to disable.
--------------	--

void PortSIP.PortSIPLib.enableAGC (Boolean state)

Enable/disable Automatic Gain Control (AGC).

Parameters

<i>state</i>	Set it to true to enable AGC, or false to disable.
--------------	--

void PortSIP.PortSIPLib.enableANS (Boolean state)

Enable/disable Audio Noise Suppression (ANS).

Parameters

<i>state</i>	Set it to true to enable ANS, or false to disable.
--------------	--

Int32 PortSIP.PortSIPLib.enableAudioQos (Boolean state)

Set the DSCP (differentiated services code point) value of QoS (Quality of Service) for audio channel.

Parameters

<i>state</i>	Set to true to enable audio QoS, and DSCP value will be 46; or false to disable audio QoS, and DSCP value will be 0.
--------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.enableVideoQos (Boolean state)

Set the DSCP (differentiated services code point) value of QoS (Quality of Service) for video channel.

Parameters

<i>state</i>	Set as true to enable video QoS and DSCP value will be 34; or false to disable Video Qos , and DSCP value will be 0.
--------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setVideoMTU (Int32 mtu)

Set the MTU size for video RTP packet.

Parameters

<i>mtu</i>	Set MTU value. Allow value ranges (512-65507). Other value will be
------------	--

modified to the default 1450.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Send OPTIONS/INFO/MESSAGE functions

Functions

- Int32 [PortSIP.PortSIPLib.sendOptions](#) (String to, String sdp)
Send OPTIONS message.
- Int32 [PortSIP.PortSIPLib.sendInfo](#) (Int32 sessionId, String mimeType, String subMimeType, String infoContents)
Send a INFO message to remote side in a call.
- Int32 [PortSIP.PortSIPLib.sendSubscription](#) (String to, String eventName)
Send a SUBSCRIBE message to subscribe an event.
- Int32 [PortSIP.PortSIPLib.terminateSubscription](#) (Int32 subscribeId)
Terminate the given subscription.
- Int32 [PortSIP.PortSIPLib.sendMessage](#) (Int32 sessionId, String mimeType, String subMimeType, byte[] message, Int32 messageLength)
Send a MESSAGE message to remote side in dialog.
- Int32 [PortSIP.PortSIPLib.sendOutOfDialogMessage](#) (String to, String mimeType, String subMimeType, Boolean isSMS, byte[] message, Int32 messageLength)
Send an out of dialog MESSAGE message to remote side.
- Int32 [PortSIP.PortSIPLib.setDefaultSubscriptionTime](#) (Int32 secs)
Set the default expiration time to be used when creating a subscription.
- Int32 [PortSIP.PortSIPLib.setDefaultPublicationTime](#) (Int32 secs)
Set the default expiration time to be used when creating a publication.
- Int32 [PortSIP.PortSIPLib.setPresenceMode](#) (Int32 mode)
Indicate the SDK uses the P2P mode for presence or presence agent mode.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.sendOptions (String to, String sdp)

Send OPTIONS message.

Parameters

<i>to</i>	The recipient of OPTIONS message.
<i>sdp</i>	The SDP of OPTIONS message. It's optional if user does not wish to send the SDP with OPTIONS message.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.sendInfo (Int32 sessionId, String mimeType, String subMimeType, String infoContents)

Send a INFO message to remote side in a call.

Parameters

<i>sessionId</i>	The session ID of call.
<i>mimeType</i>	The mime type of INFO message.
<i>subMimeType</i>	The sub mime type of INFO message.
<i>infoContents</i>	The contents that is sent with INFO message.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.sendSubscription (String to, String eventName)

Send a SUBSCRIBE message to subscribe an event.

Parameters

<i>to</i>	The user/extension to be subscribed.
<i>eventName</i>	The event name to be subscribed.

Returns

If the function succeeds, it will return the ID of SUBSCRIBE which is greater than 0. If the function fails, it will return a specific error code which is less than 0.

Remarks

Example 1, below code indicates that user/extension 101 is subscribed to MWI (Message Waiting notifications) for checking his voicemail: int32 mwiSubId = sendSubscription("sip:101@test.com", "message-summary");

Example 2, to monitor a user/extension call status, You can use code: sendSubscription(mSipLib, "100", "dialog"); Extension 100 refers to the user/extension to be monitored. Once being monitored, when extension 100 hold a call or is ringing, the onDialogStateUpdated callback will be triggered.

Int32 PortSIP.PortSIPLib.terminateSubscription (Int32 *subscribeId*)

Terminate the given subscription.

Parameters

<i>subscribeId</i>	The ID of the subscription.
--------------------	-----------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

For example, if you want stop check the MWI, use below code:

```
terminateSubscription(mwiSubId);
```

Int32 PortSIP.PortSIPLib.sendMessage (Int32 *sessionId*, String *mimeType*, String *subMimeType*, byte[] *message*, Int32 *messageLength*)

Send a MESSAGE message to remote side in dialog.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>mimeType</i>	The mime type of MESSAGE message.
<i>subMimeType</i>	The sub mime type of MESSAGE message.
<i>message</i>	The contents which is sent with MESSAGE message. Binary data allowed.
<i>messageLength</i>	The message size.

Returns

If the function succeeds, it will return a message ID that allows to track the message sending state in onSendMessageSuccess and onSendMessageFailure. If the function fails, it will return a specific error code less than 0.

Remarks

Example 1: send a plain text message. Note: to send text in other languages, please use the UTF-8 to encode the message before sending.

```
sendMessage(sessionId, "text", "plain", "hello",6);
```

Example 2: send a binary message.

```
sendMessage(sessionId, "application", "vnd.3gpp.sms", binData, binDataSize);
```

Int32 PortSIP.PortSIPLib.sendOutOfDialogMessage (String *to*, String *mimeType*, String *subMimeType*, Boolean *isSMS*, byte[] *message*, Int32 *messageLength*)

Send an out of dialog MESSAGE message to remote side.

Parameters

<i>to</i>	The message recipient, such as sip: receiver@portsip.com
<i>mimeType</i>	The mime type of MESSAGE message.
<i>subMimeType</i>	The sub mime type of MESSAGE message. @isSMS isSMS Set to YES to specify "messagetype=SMS" in the To line, or NO to disable.
<i>message</i>	The contents which is sent with MESSAGE message. Binary data allowed.
<i>messageLength</i>	The message size.

Returns

If the function succeeds, it will return a message ID that allows to track the message sending state in `onSendOutOfMessageSuccess` and `onSendOutOfMessageFailure`. If the function fails, it will return a specific error code less than 0.

Remarks

Example 1: send a plain text message. Note: to send text in other languages, please use the UTF-8 to encode the message before sending.

```
sendOutOfDialogMessage("sip:user1@sip.portsip.com", "text", "plain", false,  
"hello", 6);
```

Example 2: send a binary message.

```
sendOutOfDialogMessage("sip:user1@sip.portsip.com", "application",  
"vnd.3gpp.sms", false, binData, binDataSize);
```

Int32 PortSIP.PortSIPLib.setDefaultSubscriptionTime (Int32 secs)

Set the default expiration time to be used when creating a subscription.

Parameters

<code>secs</code>	The default expiration time of subscription.
-------------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setDefaultPublicationTime (Int32 secs)

Set the default expiration time to be used when creating a publication.

Parameters

<code>secs</code>	The default expiration time of publication.
-------------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setPresenceMode (Int32 mode)

Indicate the SDK uses the P2P mode for presence or presence agent mode.

Parameters

<code>mode</code>	0 - P2P mode; 1 - Presence Agent mode, default is P2P mode.
-------------------	---

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

Since presence agent mode requires the PBX/Server support the PUBLISH, please ensure you have your and [PortSIP](#) PBX support this feature. For more details please visit:

<https://www.portsip.com/portsip-pbx>

Presence functions

Functions

- Int32 [PortSIP.PortSIPLib.presenceSubscribe](#) (String to, String subject)
Send a SUBSCRIBE message for subscribing the contact's presence status.
 - Int32 [PortSIP.PortSIPLib.presenceTerminateSubscribe](#) (Int32 subscribeId)
Terminate the given presence subscription.
 - Int32 [PortSIP.PortSIPLib.presenceRejectSubscribe](#) (Int32 subscribeId)
Reject a presence SUBSCRIBE request which is received from contact.
 - Int32 [PortSIP.PortSIPLib.presenceAcceptSubscribe](#) (Int32 subscribeId)
Accept the presence SUBSCRIBE request which is received from contact.
 - Int32 [PortSIP.PortSIPLib.setPresenceStatus](#) (Int32 subscribeId, String stateText)
Set the presence status.
-

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.presenceSubscribe (String to, String subject)

Send a SUBSCRIBE message for subscribing the contact's presence status.

Parameters

to	The target contact. It must be like sip: contact001@sip.portsip.com .
subject	This subject text will be inserted into the SUBSCRIBE message. For example: "Hello, I'm Jason". The subject maybe in UTF-8 format. You should use UTF-8 to decode it.

Returns

If the function succeeds, it will return value subscribeId. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.presenceTerminateSubscribe (Int32 subscribeId)

Terminate the given presence subscription.

Parameters

subscribeId	The ID of the subscription.
-------------	-----------------------------

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.presenceRejectSubscribe (Int32 subscribeId)

Reject a presence SUBSCRIBE request which is received from contact.

Parameters

<i>subscribeId</i>	Subscription ID. When receiving a SUBSCRIBE request from contact, the event onPresenceRecvSubscribe will be triggered. The event includes the subscription ID.
--------------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

If the P2P presence mode is enabled, when someone subscribe your presence status, you will receive the subscribe request in the callback, and you can use this function to accept it.

Int32 PortSIP.PortSIPLib.presenceAcceptSubscribe (Int32 subscribeId)

Accept the presence SUBSCRIBE request which is received from contact.

Parameters

<i>subscribeId</i>	Subscription ID. When receiving a SUBSCRIBE request from contact, the event onPresenceRecvSubscribe will be triggered. The event will include the subscription ID.
--------------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

If the P2P presence mode is enabled, when someone subscribes your presence status, you will receive the subscription request in the callback, and you can use this function to reject it.

Int32 PortSIP.PortSIPLib.setPresenceStatus (Int32 subscribeId, String stateText)

Set the presence status.

Parameters

<i>subscribeId</i>	Subscription ID.
<i>stateText</i>	The state text of presence online. For example: "I'm here". If you want to appear as offline to others, please pass the "Offline" to "statusText" parameter.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Remarks

With P2P presence mode, when receiving a SUBSCRIBE request from contact, the event onPresenceRecvSubscribe will be triggered. The event includes the subscription ID. This

function will cause the SDK sending a NOTIFY message to update your presence status, and you must pass the correct subscribeId.

With presence agent mode, this function will cause the SDK to send a PUBLISH message to update your presence status, and you must pass 0 to the "subscribeId" parameter.

Device Manage functions.

Functions

- Int32 [PortSIP.PortSIPLib.getNumOfRecordingDevices](#) ()
Gets the count of audio devices available for audio recording.
- Int32 [PortSIP.PortSIPLib.getNumOfPlayoutDevices](#) ()
Gets the number of audio devices available for audio playout.
- Int32 [PortSIP.PortSIPLib.getRecordingDeviceName](#) (Int32 deviceIndex, StringBuilder nameUTF8, Int32 nameUTF8Length)
Gets the name of a specific recording device given by an index.
- Int32 [PortSIP.PortSIPLib.getPlayoutDeviceName](#) (Int32 deviceIndex, StringBuilder nameUTF8, Int32 nameUTF8Length)
Get the name of a specific playout device given by an index.
- Int32 [PortSIP.PortSIPLib.setSpeakerVolume](#) (Int32 volume)
Set the speaker volume level.
- Int32 [PortSIP.PortSIPLib.getSpeakerVolume](#) ()
Gets the speaker volume level.
- Int32 [PortSIP.PortSIPLib.setMicVolume](#) (Int32 volume)
Sets the microphone volume level.
- Int32 [PortSIP.PortSIPLib.getMicVolume](#) ()
Retrieves the current microphone volume.
- void [PortSIP.PortSIPLib.audioPlayLoopbackTest](#) (Boolean enable)
Use it for the audio device loop back test.
- Int32 [PortSIP.PortSIPLib.getNumOfVideoCaptureDevices](#) ()
Get the number of available capturing devices.
- Int32 [PortSIP.PortSIPLib.getVideoCaptureDeviceName](#) (Int32 deviceIndex, StringBuilder uniqueIdUTF8, Int32 uniqueIdUTF8Length, StringBuilder deviceNameUTF8, Int32 deviceNameUTF8Length)
Get the name of a specific video capture device given by an index.
- Int32 [PortSIP.PortSIPLib.showVideoCaptureSettingsDialogBox](#) (String uniqueIdUTF8, Int32 uniqueIdUTF8Length, String dialogTitle, IntPtr parentWindow, Int32 x, Int32 y)

Display the capture device property dialog box for the specified capture device.

Detailed Description

Function Documentation

Int32 PortSIP.PortSIPLib.getNumOfRecordingDevices ()

Gets the count of audio devices available for audio recording.

Returns

It will return the count of recording devices. If the function fails, it will return a specific error code less than 0.

Int32 PortSIP.PortSIPLib.getNumOfPlayoutDevices ()

Gets the number of audio devices available for audio playout.

Returns

It will return the count of playout devices. If the function fails, it will return a specific error code less than 0.

Int32 PortSIP.PortSIPLib.getRecordingDeviceName (Int32 deviceIndex, StringBuilder nameUTF8, Int32 nameUTF8Length)

Gets the name of a specific recording device given by an index.

Parameters

<i>deviceIndex</i>	Device index (0, 1, 2, ..., N-1), where N is given by <code>getNumOfRecordingDevices ()</code> . Also -1 is a valid value and will return the name of the default recording device.
<i>nameUTF8</i>	A character buffer to which the device name will be copied as a null-terminated string in UTF-8 format.
<i>nameUTF8Length</i>	The size of <i>nameUTF8</i> buffer. It cannot be less than 128.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.getPlayoutDeviceName (Int32 deviceIndex, StringBuilder nameUTF8, Int32 nameUTF8Length)

Get the name of a specific playout device given by an index.

Parameters

<i>deviceIndex</i>	
<i>deviceIndex</i>	Device index (0, 1, 2, ..., N-1), where N is given by <code>getNumOfRecordingDevices ()</code> . Also -1 is a valid value and will return the name of the default recording device.
<i>nameUTF8</i>	A character buffer to which the device name will be copied as a null-terminated string in UTF-8 format.
<i>nameUTF8Length</i>	The size of <i>nameUTF8</i> buffer. It cannot be less than 128.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setSpeakerVolume (Int32 *volume*)

Set the speaker volume level.

Parameters

<i>volume</i>	Volume level of speaker. Valid value ranges 0 - 255.
---------------	--

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.getSpeakerVolume ()

Gets the speaker volume level.

Returns

If the function succeeds, it will return the speaker volume with valid range 0 - 255. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.setMicVolume (Int32 *volume*)

Sets the microphone volume level.

Parameters

<i>volume</i>	The microphone volume level. Valid value ranges 0 - 255.
---------------	--

Returns

If the function succeeds, the return value is 0. If the function fails, the return value is a specific error code.

Int32 PortSIP.PortSIPLib.getMicVolume ()

Retrieves the current microphone volume.

Returns

If the function succeeds, it will return the microphone volume. If the function fails, it will return a specific error code.

void PortSIP.PortSIPLib.audioPlayLoopbackTest (Boolean enable)

Use it for the audio device loop back test.

Parameters

<i>enable</i>	Set to true to start audio look back test; or false to stop.
---------------	--

Int32 PortSIP.PortSIPLib.getNumOfVideoCaptureDevices ()

Get the number of available capturing devices.

Returns

It will return the count of video capturing devices. If it fails, it will return a specific error code less than 0.

Int32 PortSIP.PortSIPLib.getVideoCaptureDeviceName (Int32 deviceIndex, StringBuilder uniqueIdUTF8, Int32 uniqueIdUTF8Length, StringBuilder deviceNameUTF8, Int32 deviceNameUTF8Length)

Get the name of a specific video capture device given by an index.

Parameters

<i>deviceIndex</i>	Device index (0, 1, 2, ..., N-1), where N is given by getNumOfVideoCaptureDevices (). Also -1 is a valid value and will return the name of the default capturing device.
<i>uniqueIdUTF8</i>	Unique identifier of the capturing device.
<i>uniqueIdUTF8Length</i>	Size in bytes of uniqueIdUTF8.
<i>deviceNameUTF8</i>	A character buffer to which the device name will be copied as a null-terminated string in UTF-8 format.
<i>deviceNameUTF8Length</i>	The size of nameUTF8 buffer. It cannot be less than 128.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

Int32 PortSIP.PortSIPLib.showVideoCaptureSettingsDialogBox (String uniqueIdUTF8, Int32 uniqueIdUTF8Length, String dialogTitle, IntPtr parentWindow, Int32 x, Int32 y)

Display the capture device property dialog box for the specified capture device.

Parameters

<i>uniqueIdUTF8</i>	Unique identifier of the capture device.
<i>uniqueIdUTF8Length</i>	Size in bytes of uniqueIdUTF8.
<i>dialogTitle</i>	The title of the video settings dialog.
<i>parentWindow</i>	Parent window used for the dialog box. It should originally be a HWND.
<i>x</i>	Horizontal position for the dialog relative to the parent window, in pixels.
<i>y</i>	Vertical position for the dialog relative to the parent window, in pixels.

Returns

If the function succeeds, it will return value 0. If the function fails, it will return a specific error code.

SDK Callback events

SDK Callback events.

Modules

- [Register events](#)
Register events.
 - [Call events](#)
 - [Refer events](#)
 - [Signaling events](#)
 - [MWI events](#)
 - [DTMF events](#)
 - [INFO/OPTIONS message events](#)
 - [Presence events](#)
 - [Play audio and video file finished events](#)
 - [RTP callback events](#)
 - [Audio and video stream callback events](#)
-

Detailed Description

SDK Callback events.

Register events

Register events.

Functions

- Int32 [PortSIP.SIPCallbackEvents.onRegisterSuccess](#) (Int32 callbackIndex, Int32 callbackObject, String statusText, Int32 statusCode, StringBuilder sipMessage)
 - Int32 [PortSIP.SIPCallbackEvents.onRegisterFailure](#) (Int32 callbackIndex, Int32 callbackObject, String statusText, Int32 statusCode, StringBuilder sipMessage)
-

Detailed Description

Register events.

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onRegisterSuccess (Int32 callbackIndex, Int32 callbackObject, String statusText, Int32 statusCode, StringBuilder sipMessage)

When successfully registered to server, this event will be triggered.

Parameters

<i>callbackIndex</i>	This is a callback index passed in when creating the SDK library.
<i>callbackObject</i>	This is a callback object passed in when creating the SDK library.
<i>statusText</i>	The status text.
<i>statusCode</i>	The status code.
<i>sipMessage</i>	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onRegisterFailure (Int32 *callbackIndex*, Int32 *callbackObject*, String *statusText*, Int32 *statusCode*, StringBuilder *sipMessage*)

If registration to SIP server fails, this event will be triggered.

Parameters

<i>statusText</i>	The status text.
<i>statusCode</i>	The status code.
<i>sipMessage</i>	The SIP message received.

Call events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onInviteIncoming](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String callerDisplayName, String caller, String calleeDisplayName, String callee, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [PortSIP.SIPCallbackEvents.onInviteTrying](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onInviteSessionProgress](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsEarlyMedia, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [PortSIP.SIPCallbackEvents.onInviteRinging](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String statusText, Int32 statusCode, StringBuilder sipMessage)
- Int32 [PortSIP.SIPCallbackEvents.onInviteAnswered](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String callerDisplayName, String caller, String calleeDisplayName, String callee, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [PortSIP.SIPCallbackEvents.onInviteFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code, StringBuilder sipMessage)
- Int32 [PortSIP.SIPCallbackEvents.onInviteUpdated](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [PortSIP.SIPCallbackEvents.onInviteConnected](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onInviteBeginingForward](#) (Int32 callbackIndex, Int32 callbackObject, String forwardTo)
- Int32 [PortSIP.SIPCallbackEvents.onInviteClosed](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onDialogStateUpdated](#) (Int32 callbackIndex, Int32 callbackObject, String BLFMonitoredUri, String BLFDialogState, String BLFDialogId, String BLFDialogDirection)
- Int32 [PortSIP.SIPCallbackEvents.onRemoteHold](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onRemoteUnHold](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo)

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onInviteIncoming (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String callerDisplayName, String caller, String calleeDisplayName, String callee, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)

When the call is coming, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>callerDisplayName</i>	The display name of caller
<i>caller</i>	The caller.
<i>calleeDisplayName</i>	The display name of callee.
<i>callee</i>	The callee.
<i>audioCodecNames</i>	The matched audio codecs. It's separated by "#" if there are more than one codecs.
<i>videoCodecNames</i>	The matched video codecs. It's separated by "#" if there are more than one codecs.
<i>existsAudio</i>	If it's true, it indicates that this call includes the audio.
<i>existsVideo</i>	If it's true, it indicates that this call includes the video.
<i>sipMessage</i>	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onInviteTrying (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)

If the outgoing call is being processed, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onInviteSessionProgress (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsEarlyMedia, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)

Once the caller received the "183 session progress" message, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>audioCodecNames</i>	The matched audio codecs. It's separated by "#" if there are more than one codecs.
<i>videoCodecNames</i>	The matched video codecs. It's separated by "#" if there are more than one codecs.
<i>existsEarlyMedia</i>	If it's true, it indicates that the call has early media.
<i>existsAudio</i>	If it's true, it indicates that this call includes the audio.
<i>existsVideo</i>	If it's true, it indicates that this call includes the video.
<i>sipMessage</i>	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onInviteRinging (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String statusText, Int32 statusCode, StringBuilder sipMessage)

If the outgoing call was ringing, this event would be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>statusText</i>	The status text.
<i>statusCode</i>	The status code.
<i>sipMessage</i>	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onInviteAnswered (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String callerDisplayName, String caller, String calleeDisplayName, String callee, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)

If the remote party answered the call, this event would be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>callerDisplayName</i>	The display name of caller
<i>caller</i>	The caller.
<i>calleeDisplayName</i>	The display name of callee.
<i>callee</i>	The callee.
<i>audioCodecNames</i>	The matched audio codecs. It's separated by "#" if there are more than one codecs.
<i>videoCodecNames</i>	The matched video codecs. It's separated by "#" if there are more than one codecs.
<i>existsAudio</i>	If it's true, it indicates that this call includes the audio.
<i>existsVideo</i>	If it's true, it indicates that this call includes the video.
<i>sipMessage</i>	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onInviteFailure (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code, StringBuilder sipMessage)

If the outgoing call fails, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>reason</i>	The failure reason.
<i>code</i>	The failure code.
<i>sipMessage</i>	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onInviteUpdated (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)

This event will be triggered when remote party updates this call.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>audioCodecNames</i>	The matched audio codecs. It's separated by "#" if there are more than one codecs.
<i>videoCodecNames</i>	The matched video codecs. It's separated by "#" if there are more than one codecs.
<i>existsAudio</i>	If it's true, it indicates that this call includes the audio.

<i>existsVideo</i>	If it's true, it indicates that this call includes the video.
<i>sipMessage</i>	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onInviteConnected (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*)

This event would be triggered when UAC sent/UAS received ACK(the call is connected). Some functions (hold, updateCall etc...) can be called only after the call connected, otherwise these functions will return error.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onInviteBeginingForward (Int32 *callbackIndex*, Int32 *callbackObject*, String *forwardTo*)

If the enableCallForward method is called and a call is incoming, the call will be forwarded automatically and this event will be triggered.

Parameters

<i>forwardTo</i>	The forwarding target SIP URI.
------------------	--------------------------------

Int32 PortSIP.SIPCallbackEvents.onInviteClosed (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*)

This event is triggered once remote side closes the call.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onDialogStateUpdated (Int32 *callbackIndex*, Int32 *callbackObject*, String *BLFMonitoredUri*, String *BLFDialogState*, String *BLFDialogId*, String *BLFDialogDirection*)

If a user subscribed and his dialog status monitored, when the monitored user is holding a call or being rang, this event will be triggered

Parameters

<i>BLFMonitoredUri</i>	the monitored user's URI
<i>BLFDialogState</i>	- the status of the call
<i>BLFDialogId</i>	- the id of the call
<i>BLFDialogDirection</i>	- the direction of the call

Int32 PortSIP.SIPCallbackEvents.onRemoteHold (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*)

If the remote side placed the call on hold, this event would be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onRemoteUnHold (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*, String *audioCodecNames*, String *videoCodecNames*, Boolean *existsAudio*, Boolean *existsVideo*)

If the remote side un-hold the call, this event would be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>audioCodecNames</i>	The matched audio codecs. It's separated by "#" if there are more than one codecs.
<i>videoCodecNames</i>	The matched video codecs. It's separated by "#" if there are more than one

	codecs.
<i>existsAudio</i>	If it's true, it indicates that this call includes the audio.
<i>existsVideo</i>	If it's true, it indicates that this call includes the video.

Refer events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onReceivedRefer](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 referId, String to, String from, StringBuilder referSipMessage)
- Int32 [PortSIP.SIPCallbackEvents.onReferAccepted](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onReferRejected](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code)
- Int32 [PortSIP.SIPCallbackEvents.onTransferTrying](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onTransferRinging](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onACTVTransferSuccess](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [PortSIP.SIPCallbackEvents.onACTVTransferFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code)

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onReceivedRefer (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 referId, String to, String from, StringBuilder referSipMessage)

This event will be triggered once receiving a REFER message.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>referId</i>	The ID of the REFER message. Pass it to acceptRefer or rejectRefer
<i>to</i>	The refer target.
<i>from</i>	The sender of REFER message.
<i>referSipMessage</i>	The SIP message of "REFER". Pass it to "acceptRefer" function.

Int32 PortSIP.SIPCallbackEvents.onReferAccepted (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)

This callback will be triggered once remote side called "acceptRefer" to accept the REFER.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onReferRejected (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code)

This callback will be triggered once remote side called "rejectRefer" to reject the REFER.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>reason</i>	Reject reason.
<i>code</i>	Reject code.

Int32 PortSIP.SIPCallbackEvents.onTransferTrying (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)

When the refer call is being processed, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onTransferRinging (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)

When the refer call is ringing, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onACTVTransferSuccess (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)

When the refer call succeeds, this event will be triggered. The ACTV means Active. For example: A established the call with B, and A transferred B to C. When C accepts the refer call, A will receive this event.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

Int32 PortSIP.SIPCallbackEvents.onACTVTransferFailure (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code)

When the refer call fails, this event will be triggered. The ACTV means Active. For example: A established the call with B, and A transferred B to C. When C rejects the refer call, A will receive this event.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>reason</i>	The error reason.
<i>code</i>	The error code.

Signaling events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onReceivedSignaling](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, StringBuilder signaling)
- Int32 [PortSIP.SIPCallbackEvents.onSendingSignaling](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, StringBuilder signaling)

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onReceivedSignaling (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, StringBuilder signaling)

This event will be triggered when receiving an SIP message.

Parameters

sessionId	The session ID of the call.
signaling	The SIP message received.

Int32 PortSIP.SIPCallbackEvents.onSendingSignaling (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, StringBuilder signaling)

This event will be triggered when a SIP message sent.

Parameters

sessionId	The session ID of the call.
signaling	The SIP message sent.

MWI events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onWaitingVoiceMessage](#) (Int32 callbackIndex, Int32 callbackObject, String messageAccount, Int32 urgentNewMessageCount, Int32 urgentOldMessageCount, Int32 newMessageCount, Int32 oldMessageCount)
- Int32 [PortSIP.SIPCallbackEvents.onWaitingFaxMessage](#) (Int32 callbackIndex, Int32 callbackObject, String messageAccount, Int32 urgentNewMessageCount, Int32 urgentOldMessageCount, Int32 newMessageCount, Int32 oldMessageCount)

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onWaitingVoiceMessage (Int32 callbackIndex, Int32 callbackObject, String messageAccount, Int32 urgentNewMessageCount, Int32 urgentOldMessageCount, Int32 newMessageCount, Int32 oldMessageCount)

If there is voice message (MWI) waiting, this event will be triggered.

Parameters

messageAccount	Voice message account
urgentNewMessageCount	Urgent new message count.
urgentOldMessageCount	Urgent old message count.
newMessageCount	New message count.
oldMessageCount	Old message count.

Int32 PortSIP.SIPCallbackEvents.onWaitingFaxMessage (Int32 callbackIndex, Int32 callbackObject, String messageAccount, Int32 urgentNewMessageCount, Int32 urgentOldMessageCount, Int32 newMessageCount, Int32 oldMessageCount)

If there is fax message (MWI) waiting, this event will be triggered.

Parameters

<i>messageAccount</i>	Fax message account
<i>urgentNewMessageCount</i>	Urgent new message count.
<i>urgentOldMessageCount</i>	Urgent old message count.
<i>newMessageCount</i>	New message count.
<i>oldMessageCount</i>	Old message count.

DTMF events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onRecvDtmfTone](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 tone)
-

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onRecvDtmfTone (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 tone)

This event will be triggered when receiving a DTMF tone from remote side.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>tone</i>	DTMF tone.
code	Description
0	The DTMF tone 0.
1	The DTMF tone 1.
2	The DTMF tone 2.
3	The DTMF tone 3.
4	The DTMF tone 4.
5	The DTMF tone 5.
6	The DTMF tone 6.
7	The DTMF tone 7.
8	The DTMF tone 8.
9	The DTMF tone 9.
10	The DTMF tone *.
11	The DTMF tone #.
12	The DTMF tone A.
13	The DTMF tone B.
14	The DTMF tone C.
15	The DTMF tone D.

INFO/OPTIONS message events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onRecvOptions](#) (Int32 callbackIndex, Int32 callbackObject, StringBuilder optionsMessage)
 - Int32 [PortSIP.SIPCallbackEvents.onRecvInfo](#) (Int32 callbackIndex, Int32 callbackObject, StringBuilder infoMessage)
 - Int32 [PortSIP.SIPCallbackEvents.onRecvNotifyOfSubscription](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId, StringBuilder notifyMsg, byte[] contentData, Int32 contentLength)
 - Int32 [PortSIP.SIPCallbackEvents.onSubscriptionFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId, Int32 statusCode)
 - Int32 [PortSIP.SIPCallbackEvents.onSubscriptionTerminated](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId)
-

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onRecvOptions (Int32 *callbackIndex*, Int32 *callbackObject*, StringBuilder *optionsMessage*)

This event will be triggered when receiving the OPTIONS message.

Parameters

<i>optionsMessage</i>	The received whole OPTIONS message in text format.
-----------------------	--

Int32 PortSIP.SIPCallbackEvents.onRecvInfo (Int32 *callbackIndex*, Int32 *callbackObject*, StringBuilder *infoMessage*)

This event will be triggered when receiving the INFO message.

Parameters

<i>infoMessage</i>	The received whole INFO message in text format.
--------------------	---

Int32 PortSIP.SIPCallbackEvents.onRecvNotifyOfSubscription (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *subscribeId*, StringBuilder *notifyMsg*, byte[] *contentData*, Int32 *contentLength*)

This event will be triggered when receiving a NOTIFY message of the subscription.

Parameters

<i>subscribeId</i>	The ID of SUBSCRIBE request.
<i>notifyMessage</i>	The received INFO message in text format.
<i>contentData</i>	The received message body. It's can be either text or binary data.
<i>contentLength</i>	The length of "messageData".

Int32 PortSIP.SIPCallbackEvents.onSubscriptionFailure (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeld, Int32 statusCode)

This event will be triggered on sending SUBSCRIBE failure.

Parameters

<i>subscribeId</i>	The ID of SUBSCRIBE request.
<i>statusCode</i>	The status code.

Int32 PortSIP.SIPCallbackEvents.onSubscriptionTerminated (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeld)

This event will be triggered when a SUBSCRIPTION is terminated or expired.

Parameters

<i>subscribeId</i>	The ID of SUBSCRIBE request.
--------------------	------------------------------

Presence events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onPresenceRecvSubscribe](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId, String fromDisplayName, String from, String subject)
- Int32 [PortSIP.SIPCallbackEvents.onPresenceOnline](#) (Int32 callbackIndex, Int32 callbackObject, String fromDisplayName, String from, String stateText)
- Int32 [PortSIP.SIPCallbackEvents.onPresenceOffline](#) (Int32 callbackIndex, Int32 callbackObject, String fromDisplayName, String from)
- Int32 [PortSIP.SIPCallbackEvents.onRecvMessage](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String mimeType, String subMimeType, byte[] messageData, Int32 messageDataLength)
- Int32 [PortSIP.SIPCallbackEvents.onRecvOutOfDialogMessage](#) (Int32 callbackIndex, Int32 callbackObject, String fromDisplayName, String from, String toDisplayName, String to, String mimeType, String subMimeType, byte[] messageData, Int32 messageDataLength)
- Int32 [PortSIP.SIPCallbackEvents.onSendMessageSuccess](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 messageId)
- Int32 [PortSIP.SIPCallbackEvents.onSendMessageFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 messageId, String reason, Int32 code)
- Int32 [PortSIP.SIPCallbackEvents.onSendOutOfDialogMessageSuccess](#) (Int32 callbackIndex, Int32 callbackObject, Int32 messageId, String fromDisplayName, String from, String toDisplayName, String to)
- Int32 [PortSIP.SIPCallbackEvents.onSendOutOfDialogMessageFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 messageId, String fromDisplayName, String from, String toDisplayName, String to, String reason, Int32 code)

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onPresenceRecvSubscribe (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeld, String fromDisplayName, String from, String subject)

This event will be triggered when receiving the SUBSCRIBE request from a contact.

Parameters

<i>subscribeId</i>	The ID of SUBSCRIBE request.
<i>fromDisplayName</i>	The display name of contact.
<i>from</i>	The contact who sends the SUBSCRIBE request.
<i>subject</i>	The subject of the SUBSCRIBE request.

Int32 PortSIP.SIPCallbackEvents.onPresenceOnline (Int32 *callbackIndex*, Int32 *callbackObject*, String *fromDisplayName*, String *from*, String *stateText*)

When the contact is online or changes presence status, this event will be triggered.

Parameters

<i>fromDisplayName</i>	The display name of contact.
<i>from</i>	The contact who sends the SUBSCRIBE request.
<i>stateText</i>	The presence status text.

Int32 PortSIP.SIPCallbackEvents.onPresenceOffline (Int32 *callbackIndex*, Int32 *callbackObject*, String *fromDisplayName*, String *from*)

When the contact goes offline, this event will be triggered.

Parameters

<i>fromDisplayName</i>	The display name of contact.
<i>from</i>	The contact who sends the SUBSCRIBE request

Int32 PortSIP.SIPCallbackEvents.onRecvMessage (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*, String *mimeType*, String *subMimeType*, byte[] *messageData*, Int32 *messageDataLength*)

This event will be triggered when receiving a MESSAGE message in dialog.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>mimeType</i>	The message mime type.
<i>subMimeType</i>	The message sub mime type.
<i>messageData</i>	The received message body. It can be text or binary data.
<i>messageDataLength</i>	The length of "messageData".

Int32 PortSIP.SIPCallbackEvents.onRecvOutOfDialogMessage (Int32 *callbackIndex*, Int32 *callbackObject*, String *fromDisplayName*, String *from*, String *toDisplayName*, String *to*, String *mimeType*, String *subMimeType*, byte[] *messageData*, Int32 *messageDataLength*)

This event will be triggered when receiving a MESSAGE message out of dialog. For example: pager message.

Parameters

<i>fromDisplayName</i>	The display name of sender.
<i>from</i>	The message sender.
<i>toDisplayName</i>	The display name of recipient.
<i>to</i>	The recipient.
<i>mimeType</i>	The message mime type.
<i>subMimeType</i>	The message sub mime type.
<i>messageData</i>	The received message body. It can be text or binary data.
<i>messageDataLength</i>	The length of "messageData".

Int32 PortSIP.SIPCallbackEvents.onSendMessageSuccess (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*, Int32 *messageId*)

If the message is sent successfully in dialog, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>messageId</i>	The message ID. It's equal to the return value of sendMessage function.

Int32 PortSIP.SIPCallbackEvents.onSendMessageFailure (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*, Int32 *messageId*, String *reason*, Int32 *code*)

If the message fails to be sent out of dialog, this event will be triggered.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>messageId</i>	The message ID. It's equal to the return value of sendMessage function.
<i>reason</i>	The failure reason.
<i>code</i>	Failure code.

Int32 PortSIP.SIPCallbackEvents.onSendOutOfDialogMessageSuccess (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *messageId*, String *fromDisplayName*, String *from*, String *toDisplayName*, String *to*)

If the message is sent succeeded out of dialog, this event will be triggered.

Parameters

<i>messageId</i>	The message ID. It's equal to the return value of SendOutOfDialogMessage function.
<i>fromDisplayName</i>	The display name of message sender.
<i>from</i>	The message sender.
<i>toDisplayName</i>	The display name of message recipient.
<i>to</i>	The message receiver.

Int32 PortSIP.SIPCallbackEvents.onSendOutOfDialogMessageFailure (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *messageId*, String *fromDisplayName*, String *from*, String *toDisplayName*, String *to*, String *reason*, Int32 *code*)

If the message was sent failure out of dialog, this event will be triggered.

Parameters

<i>messageId</i>	The message ID. It's equal to the return value of SendOutOfDialogMessage function.
<i>fromDisplayName</i>	The display name of message sender
<i>from</i>	The message sender.
<i>toDisplayName</i>	The display name of message recipient.
<i>to</i>	The message recipient.
<i>reason</i>	The failure reason.
<i>code</i>	The failure code.

Play audio and video file finished events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onPlayAudioFileFinished](#) (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*, String *fileName*)
- Int32 [PortSIP.SIPCallbackEvents.onPlayVideoFileFinished](#) (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*)

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onPlayAudioFileFinished (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*, String *fileName*)

If playAudioFileToRemote function is called with no loop mode, this event will be triggered once the file play finished.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>fileName</i>	The name of the file played.

Int32 PortSIP.SIPCallbackEvents.onPlayVideoFileFinished (Int32 *callbackIndex*, Int32 *callbackObject*, Int32 *sessionId*)

If playVideoFileToRemote function is called with no loop mode, this event will be triggered once the file play finished.

Parameters

<i>sessionId</i>	The session ID of the call.
------------------	-----------------------------

RTP callback events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onRTPPacketCallback](#) (IntPtr *callbackObject*, Int32 *sessionId*, Int32 *mediaType*, Int32 *direction*, byte[] *RTPPacket*, Int32 *packetSize*)
-

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onRTPPacketCallback (IntPtr *callbackObject*, Int32 *sessionId*, Int32 *mediaType*, Int32 *direction*, byte[] *RTPPacket*, Int32 *packetSize*)

If enableRtpCallback function is called to enable the RTP callback, this event will be triggered once receiving a RTP packet or a RTP packet sent.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>mediaType</i>	If the received RTP packet is audio this parameter is 0 video this parameter is 1 screen this parameter is 2
<i>direction</i>	The RTP stream callback direction.

Type	Description
DIRECTION_SEND	Callback the send RTP stream for one channel based on the given sessionId.
DIRECTION_RECV	Callback the received RTP stream for one channel based on the given sessionId.

Parameters

<i>RTPPacket</i>	The memory of whole RTP packet.
<i>packetSize</i>	The size of received RTP Packet.

Note

Don't call any SDK API functions in this event directly. If you want to call the API functions or other code which is time-consuming, you should post a message to another thread and execute SDK API functions or other code in another thread.

Audio and video stream callback events

Functions

- Int32 [PortSIP.SIPCallbackEvents.onAudioRawCallback](#) (IntPtr callbackObject, Int32 sessionId, Int32 callbackType, byte[] data, Int32 dataLength, Int32 samplingFreqHz)
- Int32 [PortSIP.SIPCallbackEvents.onVideoRawCallback](#) (IntPtr callbackObject, Int32 sessionId, Int32 callbackType, Int32 width, Int32 height, byte[] data, Int32 dataLength)

Detailed Description

Function Documentation

Int32 PortSIP.SIPCallbackEvents.onAudioRawCallback (IntPtr callbackObject, Int32 sessionId, Int32 callbackType, byte[] data, Int32 dataLength, Int32 samplingFreqHz)

This event will be triggered once receiving the audio packets if called enableAudioStreamCallback function.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>audioCallbackMod e</i>	The type that is passed in enableAudioStreamCallback function.
<i>data</i>	The memory of audio stream. It's in PCM format.
<i>dataLength</i>	The data size.
<i>samplingFreqHz</i>	The audio stream sample in HZ. For example, it's 8000 or 16000.

Note

Don't call any SDK API functions in this event directly. If you want to call the API functions or other code which is time-consuming, you should post a message to another thread and execute SDK API functions or other code in another thread.

Int32 PortSIP.SIPCallbackEvents.onVideoRawCallback (IntPtr callbackObject, Int32 sessionId, Int32 callbackType, Int32 width, Int32 height, byte[] data, Int32 dataLength)

This event will be triggered once receiving the video packets if called enableVideoStreamCallback function.

Parameters

<i>sessionId</i>	The session ID of the call.
<i>videoCallbackMod e</i>	The type which is passed in enableVideoStreamCallback function.

<i>width</i>	The width of video image.
<i>height</i>	The height of video image.
<i>data</i>	The memory of video stream. It's in YUV420 format, YV12.
<i>dataLength</i>	The data size.

Note

Don't call any SDK API functions in this event directly. If you want to call the API functions or other code which is time-consuming, you should post a message to another thread and execute SDK API functions or other code in another thread.

Namespace Documentation

PortSIP Namespace Reference

Classes

- class [PortSIP_Errors](#)
- class [PortSIPLib](#)
- interface [SIPCallbackEvents](#)

Enumerations

- enum [AUDIOCODEC_TYPE](#) : int { [AUDIOCODEC_NONE](#) = -1, [AUDIOCODEC_TYPE.AUDIOCODEC_G729](#) = 18, [AUDIOCODEC_TYPE.AUDIOCODEC_PCMA](#) = 8, [AUDIOCODEC_TYPE.AUDIOCODEC_PCMU](#) = 0, [AUDIOCODEC_TYPE.AUDIOCODEC_GSM](#) = 3, [AUDIOCODEC_TYPE.AUDIOCODEC_G722](#) = 9, [AUDIOCODEC_TYPE.AUDIOCODEC_ILBC](#) = 97, [AUDIOCODEC_TYPE.AUDIOCODEC_AMR](#) = 98, [AUDIOCODEC_TYPE.AUDIOCODEC_AMRWB](#) = 99, [AUDIOCODEC_TYPE.AUDIOCODEC_SPEEX](#) = 100, [AUDIOCODEC_TYPE.AUDIOCODEC_SPEEXWB](#) = 102, [AUDIOCODEC_TYPE.AUDIOCODEC_ISACWB](#) = 103, [AUDIOCODEC_TYPE.AUDIOCODEC_ISACSWB](#) = 104, [AUDIOCODEC_TYPE.AUDIOCODEC_G7221](#) = 121, [AUDIOCODEC_TYPE.AUDIOCODEC_OPUS](#) = 105, [AUDIOCODEC_TYPE.AUDIOCODEC_DTMF](#) = 101 }
- Audio codec type.*
- enum [VIDEOCODEC_TYPE](#) : int { [VIDEOCODEC_TYPE.VIDEO_CODE_NONE](#) = -1, [VIDEOCODEC_TYPE.VIDEO_CODEC_I420](#) = 113, [VIDEOCODEC_TYPE.VIDEO_CODEC_H263](#) = 34, [VIDEOCODEC_TYPE.VIDEO_CODEC_H263_1998](#) = 115, [VIDEOCODEC_TYPE.VIDEO_CODEC_H264](#) = 125, [VIDEOCODEC_TYPE.VIDEO_CODEC_VP8](#) = 120, [VIDEOCODEC_TYPE.VIDEO_CODEC_VP9](#) = 122 }
- Video codec type.*
- enum [AUDIO_RECORDING_FILEFORMAT](#) : int { [AUDIO_RECORDING_FILEFORMAT.FILEFORMAT_WAVE](#) = 1, [AUDIO_RECORDING_FILEFORMAT.FILEFORMAT_AMR](#) }
- The audio record file format.*
- enum [RECORD_MODE](#) : int { [RECORD_MODE.RECORD_NONE](#) = 0, [RECORD_MODE.RECORD_RECV](#) = 1, [RECORD_MODE.RECORD_SEND](#), [RECORD_MODE.RECORD_BOTH](#) }
- The audio/Video record mode.*
- enum [DIRECTION_MODE](#) : int { [DIRECTION_MODE.DIRECTION_NONE](#) = 0, [DIRECTION_MODE.DIRECTION_SEND_RECV](#) = 1, [DIRECTION_MODE.DIRECTION_SEND](#), [DIRECTION_MODE.DIRECTION_RECV](#), [DIRECTION_MODE.DIRECTION_INACTIVE](#) }
- The direction.*
- enum [PORTSIP_LOG_LEVEL](#) : int { [PORTSIP_LOG_NONE](#) = -1, [PORTSIP_LOG_ERROR](#) = 1, [PORTSIP_LOG_WARNING](#) = 2, [PORTSIP_LOG_INFO](#) = 3, [PORTSIP_LOG_DEBUG](#) = 4 }
- Log level.*
- enum [SRTP_POLICY](#) : int { [SRTP_POLICY.SRTP_POLICY_NONE](#) = 0, [SRTP_POLICY.SRTP_POLICY_FORCE](#), [SRTP_POLICY.SRTP_POLICY_PREFER](#) }

SRTP Policy.

- enum [TRANSPORT_TYPE](#) : int { [TRANSPORT_TYPE.TRANSPORT_UDP](#) = 0, [TRANSPORT_TYPE.TRANSPORT_TLS](#), [TRANSPORT_TYPE.TRANSPORT_TCP](#), [TRANSPORT_TYPE.TRANSPORT_PERS](#) }
Transport for SIP signaling.
 - enum [SESSION_REFRESH_MODE](#) : int { [SESSION_REFRESH_MODE.SESSION_REFRESH_UAC](#) = 0, [SESSION_REFRESH_MODE.SESSION_REFRESH_UAS](#) }
The session refreshment by UAC or UAS.
 - enum [DTMF_METHOD](#) { [DTMF_METHOD.DTMF_RFC2833](#) = 0, [DTMF_METHOD.DTMF_INFO](#) = 1 }
send DTMF tone with two methods
-

Detailed Description

[PortSIP](#) The [PortSIP](#) VoIP SDK namespace

Enumeration Type Documentation

enum [PortSIP.AUDIOCODEC_TYPE](#) : int[strong]

Audio codec type.

Enumerator:

AUDIOCODEC_G729	G729 8KHZ 8kbit/s.
AUDIOCODEC_P_CMA	PCMA/G711 A-law 8KHZ 64kbit/s.
AUDIOCODEC_P_CMU	PCM/G711 1/4-law 8KHZ 64kbit/s.
AUDIOCODEC_GSM	GSM 8KHZ 13kbit/s.
AUDIOCODEC_G722	G722 16KHZ 64kbit/s.
AUDIOCODEC_I_LBC	iLBC 8KHZ 30ms-13kbit/s 20 ms-15kbit/s
AUDIOCODEC_AMR	Adaptive Multi-Rate (AMR) 8KHZ (4.75,5.15,5.90,6.70,7.40,7.95,10.20,12.20)kbit/s.
AUDIOCODEC_AMRWB	Adaptive Multi-Rate Wideband (AMR-WB)16KHZ (6.60,8.85,12.65,14.25,15.85,18.25,19.85,23.05,23.85)kbit/s.
AUDIOCODEC_S_PEEX	SPEEX 8KHZ (2-24)kbit/s.
AUDIOCODEC_S_PEEWB	SPEEX 16KHZ (4-42)kbit/s.
AUDIOCODEC_I_SACWB	internet Speech Audio Codec(iSAC) 16KHZ (32-54)kbit/s

AUDIOCODEC_I_SACSWB	internet Speech Audio Codec(iSAC) 16KHZ (32-160)kbit/s
AUDIOCODEC_G7221	G722.1 16KHZ (16,24,32)kbit/s.
AUDIOCODEC_OPUS	OPUS 48KHZ 32kbit/s.
AUDIOCODEC_DTMF	DTMF RFC 2833.

enum PortSIP.VIDEOCODEC_TYPE : int[strong]

Video codec type.

Enumerator:

VIDEO_CODE_N_ONE	Do not use Video codec.
VIDEO_CODEC_I420	I420/YUV420 Raw Video format. Used with startRecord only.
VIDEO_CODEC_H263	H263 video codec.
VIDEO_CODEC_H263_1998	H263+/H263 1998 video codec.
VIDEO_CODEC_H264	H264 video codec.
VIDEO_CODEC_VP8	VP8 video codec.
VIDEO_CODEC_VP9	VP9 video codec.

enum PortSIP.AUDIO_RECORDING_FILEFORMAT : int[strong]

The audio record file format.

Enumerator:

FILEFORMAT_W_AVE	The record audio file is in WAVE format.
FILEFORMAT_A_MR	The record audio file is in AMR format - all voice data are compressed by AMR codec.

enum PortSIP.RECORD_MODE : int[strong]

The audio/Video record mode.

Enumerator:

RECORD_NONE	Not Record.
RECORD_RECV	Only record the received data.
RECORD_SEND	Only record the sent data.
RECORD_BOTH	Record both received and sent data.

enum PortSIP.DIRECTION_MODE : int[strong]

The direction.

Enumerator:

DIRECTION_NO_NE	NOT EXIST.
DIRECTION_SE_ND_RECV	both received and sent.
DIRECTION_SE_ND	Only the sent.
DIRECTION_RECV	Only the received .
DIRECTION_INACTIVE	INACTIVE.

enum PortSIP.SRTP_POLICY : int[strong]

SRTP Policy.

Enumerator:

SRTP_POLICY_NONE	Do not use SRTP. The SDK can receive the encrypted call(SRTP) and unencrypted call both, but can't place outgoing encrypted call.
SRTP_POLICY_FORCE	All calls must use SRTP. The SDK allows to receive encrypted call and place outgoing encrypted call only.
SRTP_POLICY_PREFER	Top priority for using SRTP. The SDK allows to receive encrypted and decrypted call, and to place outgoing encrypted call and unencrypted call.

enum PortSIP.TRANSPORT_TYPE : int[strong]

Transport for SIP signaling.

Enumerator:

TRANSPORT_U DP	UDP Transport.
TRANSPORT_TL S	Tls Transport.
TRANSPORT_TC P	TCP Transport.
TRANSPORT_PERS	PERS is the PortSIP private transport for anti SIP blocking. It must be used with the PERS Server http://www.portsip.com/pers.html .

enum [PortSIP.SESSION_REFRESH_MODE](#) : int[strong]

The session refreshment by UAC or UAS.

Enumerator:

SESSION_REFER ESH_UAC	The session refreshment by UAC.
SESSION_REFER ESH_UAS	The session refreshment by UAS.

enum [PortSIP.DTMF_METHOD](#) [strong]

send DTMF tone with two methods

Enumerator:

DTMF_RFC2833	Send DTMF tone with RFC 2833. Recommended.
DTMF_INFO	Send DTMF tone with SIP INFO.

Class Documentation

PortSIP.PortSIP_Error Class Reference

Static Public Attributes

- static readonly int **INVALID_SESSION_ID** = -1
- static readonly int **CONFERENCE_SESSION_ID** = 0x7FFF
- static readonly int **ECoreAlreadyInitialized** = -60000
- static readonly int **ECoreNotInitialized** = -60001
- static readonly int **ECoreSDKObjectNull** = -60002
- static readonly int **ECoreArgumentNull** = -60003
- static readonly int **ECoreInitializeWinsockFailure** = -60004
- static readonly int **ECoreUserNameAuthNameEmpty** = -60005
- static readonly int **ECoreInitializeStackFailure** = -60006
- static readonly int **ECorePortOutOfRange** = -60007
- static readonly int **ECoreAddTcpTransportFailure** = -60008
- static readonly int **ECoreAddTlsTransportFailure** = -60009
- static readonly int **ECoreAddUdpTransportFailure** = -60010
- static readonly int **ECoreMiniAudioPortOutOfRange** = -60011
- static readonly int **ECoreMaxAudioPortOutOfRange** = -60012
- static readonly int **ECoreMiniVideoPortOutOfRange** = -60013
- static readonly int **ECoreMaxVideoPortOutOfRange** = -60014
- static readonly int **ECoreMiniAudioPortNotEvenNumber** = -60015
- static readonly int **ECoreMaxAudioPortNotEvenNumber** = -60016
- static readonly int **ECoreMiniVideoPortNotEvenNumber** = -60017
- static readonly int **ECoreMaxVideoPortNotEvenNumber** = -60018
- static readonly int **ECoreAudioVideoPortOverlapped** = -60019
- static readonly int **ECoreAudioVideoPortRangeTooSmall** = -60020
- static readonly int **ECoreAlreadyRegistered** = -60021
- static readonly int **ECoreSIPServerEmpty** = -60022
- static readonly int **ECoreExpiresValueTooSmall** = -60023
- static readonly int **ECoreCallIdNotFound** = -60024
- static readonly int **ECoreNotRegistered** = -60025
- static readonly int **ECoreCalleeEmpty** = -60026
- static readonly int **ECoreInvalidUri** = -60027
- static readonly int **ECoreAudioVideoCodecEmpty** = -60028
- static readonly int **ECoreNoFreeDialogSession** = -60029
- static readonly int **ECoreCreateAudioChannelFailed** = -60030
- static readonly int **ECoreSessionTimerValueTooSmall** = -60040
- static readonly int **ECoreAudioHandleNull** = -60041
- static readonly int **ECoreVideoHandleNull** = -60042
- static readonly int **ECoreCallIsClosed** = -60043
- static readonly int **ECoreCallAlreadyHold** = -60044
- static readonly int **ECoreCallNotEstablished** = -60045
- static readonly int **ECoreCallNotHold** = -60050
- static readonly int **ECoreSipMessageEmpty** = -60051
- static readonly int **ECoreSipHeaderNotExist** = -60052
- static readonly int **ECoreSipHeaderValueEmpty** = -60053
- static readonly int **ECoreSipHeaderBadFormed** = -60054
- static readonly int **ECoreBufferTooSmall** = -60055
- static readonly int **ECoreSipHeaderValueListEmpty** = -60056
- static readonly int **ECoreSipHeaderParserEmpty** = -60057
- static readonly int **ECoreSipHeaderValueListNull** = -60058
- static readonly int **ECoreSipHeaderNameEmpty** = -60059
- static readonly int **ECoreAudioSampleNotmultiple** = -60060
- static readonly int **ECoreAudioSampleOutOfRange** = -60061
- static readonly int **ECoreInviteSessionNotFound** = -60062

- static readonly int **ECoreStackException** = -60063
- static readonly int **ECoreMimeTypeUnknown** = -60064
- static readonly int **ECoreDataSizeTooLarge** = -60065
- static readonly int **ECoreSessionNumsOutOfRange** = -60066
- static readonly int **ECoreNotSupportCallbackMode** = -60067
- static readonly int **ECoreNotFoundSubscribeId** = -60068
- static readonly int **ECoreCodecNotSupport** = -60069
- static readonly int **ECoreCodecParameterNotSupport** = -60070
- static readonly int **ECorePayloadOutOfRange** = -60071
- static readonly int **ECorePayloadHasExist** = -60072
- static readonly int **ECoreFixPayloadCantChange** = -60073
- static readonly int **ECoreCodecTypeInvalid** = -60074
- static readonly int **ECoreCodecWasExist** = -60075
- static readonly int **ECorePayloadTypeInvalid** = -60076
- static readonly int **ECoreArgumentTooLong** = -60077
- static readonly int **ECoreMiniRtpPortMustIsEvenNum** = -60078
- static readonly int **ECoreCallInHold** = -60079
- static readonly int **ECoreNotIncomingCall** = -60080
- static readonly int **ECoreCreateMediaEngineFailure** = -60081
- static readonly int **ECoreAudioCodecEmptyButAudioEnabled** = -60082
- static readonly int **ECoreVideoCodecEmptyButVideoEnabled** = -60083
- static readonly int **ECoreNetworkInterfaceUnavailable** = -60084
- static readonly int **ECoreWrongDTMFTone** = -60085
- static readonly int **ECoreWrongLicenseKey** = -60086
- static readonly int **ECoreTrialVersionLicenseKey** = -60087
- static readonly int **ECoreOutgoingAudioMuted** = -60088
- static readonly int **ECoreOutgoingVideoMuted** = -60089
- static readonly int **ECoreFailedCreateSdp** = -60090
- static readonly int **ECoreTrialVersionExpired** = -60091
- static readonly int **ECoreStackFailure** = -60092
- static readonly int **ECoreTransportExists** = -60093
- static readonly int **ECoreUnsupportTransport** = -60094
- static readonly int **ECoreAllowOnlyOneUser** = -60095
- static readonly int **ECoreUserNotFound** = -60096
- static readonly int **ECoreTransportsIncorrect** = -60097
- static readonly int **ECoreCreateTransportFailure** = -60098
- static readonly int **ECoreTransportNotSet** = -60099
- static readonly int **ECoreECreateSignalingFailure** = -60100
- static readonly int **ECoreArgumentIncorrect** = -60101
- static readonly int **EAudioFileNameEmpty** = -70000
- static readonly int **EAudioChannelNotFound** = -70001
- static readonly int **EAudioStartRecordFailure** = -70002
- static readonly int **EAudioRegisterRecodingFailure** = -70003
- static readonly int **EAudioRegisterPlaybackFailure** = -70004
- static readonly int **EAudioGetStatisticsFailure** = -70005
- static readonly int **EAudioIsPlaying** = -70006
- static readonly int **EAudioPlayObjectNotExist** = -70007
- static readonly int **EAudioPlaySteamNotEnabled** = -70008
- static readonly int **EAudioRegisterCallbackFailure** = -70009
- static readonly int **EAudioCreateAudioConferenceFailure** = -70010
- static readonly int **EAudioOpenPlayFileFailure** = -70011
- static readonly int **EAudioPlay FileModeNotSupport** = -70012
- static readonly int **EAudioPlay FileFormatNotSupport** = -70013
- static readonly int **EAudioPlay SteamAlreadyEnabled** = -70014
- static readonly int **EAudioCreate RecordFileFailure** = -70015
- static readonly int **EAudioCodecNotSupport** = -70016
- static readonly int **EAudioPlay FileNotEnabled** = -70017
- static readonly int **EAudioPlay FileUnknownSeekOrigin** = -70018
- static readonly int **EAudioCant SetDeviceIdDuringCall** = -70019
- static readonly int **EAudioVolumeOutOfRange** = -70020

- static readonly int **EVideoFileNameEmpty** = -80000
- static readonly int **EVideoGetDeviceNameFailure** = -80001
- static readonly int **EVideoGetDeviceIdFailure** = -80002
- static readonly int **EVideoStartCaptureFailure** = -80003
- static readonly int **EVideoChannelNotFound** = -80004
- static readonly int **EVideoStartSendFailure** = -80005
- static readonly int **EVideoGetStatisticsFailure** = -80006
- static readonly int **EVideoStartPlayAviFailure** = -80007
- static readonly int **EVideoSendAviFileFailure** = -80008
- static readonly int **EVideoRecordUnknowCodec** = -80009
- static readonly int **EVideoCantSetDeviceIdDuringCall** = -80010
- static readonly int **EVideoUnsupportCaptureRotate** = -80011
- static readonly int **EVideoUnsupportCaptureResolution** = -80012
- static readonly int **ECameraSwitchTooOften** = -80013
- static readonly int **EMTUOutOfRange** = -80014
- static readonly int **EDeviceGetDeviceNameFailure** = -90001

The documentation for this class was generated from the following file:

- [PortSIP_Errors.cs](#)

PortSIP.PortSIPLib Class Reference

Public Member Functions

- **PortSIPLib** (Int32 callbackIndex, Int32 callbackObject, [SIPCallbackEvents](#) callbackevents)
● Boolean **createCallbackHandlers** ()
● void **releaseCallbackHandlers** ()
● Int32 [initialize](#) ([TRANSPORT_TYPE](#) transportType, String localIp, Int32 localSIPPort, [PORTSIP_LOG_LEVEL](#) logLevel, String filePath, Int32 maxCallSessions, String sipAgentString, Int32 audioDeviceLayer, Int32 videoDeviceLayer, String TLSCertificatesRootPath, String TLSCipherList, Boolean verifyTLSCertificate)
Initialize the SDK.

- void [unInitialize](#) ()
Un-initialize the SDK and release resources.

- Int32 [getVersion](#) (out Int32 majorVersion, out Int32 minorVersion)
Get the current version number of the SDK.

- Int32 [setLicenseKey](#) (String key)
Set the license key. It must be called before setUser function.

- Int32 [getNICNums](#) ()
Get the Network Interface Card numbers.

- Int32 [getLocalIpAddress](#) (Int32 index, StringBuilder ip, Int32 ipSize)
Get the local IP address by Network Interface Card index.

- Int32 [setUser](#) (String userName, String displayName, String authName, String password, String sipDomain, String sipServerAddr, Int32 sipServerPort, String stunServerAddr, Int32 stunServerPort, String outboundServerAddr, Int32 outboundServerPort)
Set user account info.

- void [removeUser](#) ()
Remove the user. It will un-register from SIP server given that the user is already registered.

- Int32 [setDisplayname](#) (String displayName)
Set the display name of user.

- Int32 [setInstanceId](#) (String uuid)
Set outbound (RFC5626) instanceId to be used in contact headers.

- Int32 [registerServer](#) (Int32 expires, Int32 retryTimes)
Register to SIP proxy server (login to server).

- Int32 [unRegisterServer](#) ()
Un-register from the SIP proxy server.

- Int32 [enableRport](#) (Boolean enable)

Enable/disable rport(RFC3581).

- Int32 [enableEarlyMedia](#) (Boolean enable)
Enable/disable Early Media.
- Int32 [enableReliableProvisional](#) (Boolean enable)
Enable/disable PRACK.
- Int32 [enable3GppTags](#) (Boolean enable)
Enable/disable the 3Gpp tags, including "ims.icsi.mmtel" and "g.3gpp.smsip".
- void [enableCallbackSignaling](#) (Boolean enableSending, Boolean enableReceived)
Enable/disable to callback the SIP messages.
- Int32 [enableRtpCallback](#) (Int32 callbackObject, Int32 sessionId, Int32 mediaType, Int32 directionMode)
Set the RTP callbacks to allow access to the sent and received RTP packets. The onRTPPacketCallback events will be triggered.
- Int32 [addAudioCodec](#) ([AUDIOCODEC_TYPE](#) codecType)
Enable an audio codec. It will be appears in SDP.
- Int32 [addVideoCodec](#) ([VIDEOCODEC_TYPE](#) codecType)
Enable a video codec. It will appear in SDP.
- Boolean [isAudioCodecEmpty](#) ()
Detect if enabled audio codecs is empty or not.
- Boolean [isVideoCodecEmpty](#) ()
Detect if enabled video codecs is empty or not.
- Int32 [setAudioCodecPayloadType](#) ([AUDIOCODEC_TYPE](#) codecType, Int32 payloadType)
Set the RTP payload type for dynamic audio codec.
- Int32 [setVideoCodecPayloadType](#) ([VIDEOCODEC_TYPE](#) codecType, Int32 payloadType)
Set the RTP payload type for dynamic Video codec.
- void [clearAudioCodec](#) ()
Remove all enabled audio codecs.
- void [clearVideoCodec](#) ()
Remove all enabled video codecs.
- Int32 [setAudioCodecParameter](#) ([AUDIOCODEC_TYPE](#) codecType, String parameter)
Set the codec parameter for audio codec.
- Int32 [setVideoCodecParameter](#) ([VIDEOCODEC_TYPE](#) codecType, String parameter)
Set the codec parameter for video codec.

- Int32 [setSrtpPolicy \(SRTP_POLICY srtpPolicy, Boolean allowSrtpOverUnsecureTransport\)](#)
Set the SRTP policy.
- Int32 [setRtpPortRange \(Int32 minimumRtpPort, Int32 maximumRtpPort\)](#)
Set the RTP ports range for RTP streaming.
- Int32 [enableCallForward \(Boolean forBusyOnly, String forwardTo\)](#)
Enable call forward.
- Int32 [disableCallForward \(\)](#)
Disable the call forwarding. The SDK is not forwarding any incoming call after this function is called.
- Int32 [enableSessionTimer \(Int32 timerSeconds, SESSION_REFRESH_MODE refreshMode\)](#)
Allows to periodically refresh Session Initiation Protocol (SIP) sessions by sending INVITE requests repeatedly.
- Int32 [disableSessionTimer \(\)](#)
Disable the session timer.
- void [setDoNotDisturb \(Boolean state\)](#)
Enable the "Do not disturb" to enable/disable.
- Int32 [enableAutoCheckMwi \(Boolean state\)](#)
Allows to enable/disable the check MWI (Message Waiting Indication) automatically.
- Int32 [setRtpKeepAlive \(Boolean state, Int32 keepAlivePayloadType, Int32 deltaTransmitTimeMS\)](#)
Enable or disable to send RTP keep-alive packet when the call is established.
- Int32 [setKeepAliveTime \(Int32 keepAliveTime\)](#)
Enable or disable to send SIP keep-alive packet.
- Int32 [getSipMessageHeaderValue \(String sipMessage, String headerName, StringBuilder headerValue, Int32 headerValueLength\)](#)
Access the SIP header of SIP message.
- Int32 [addSipMessageHeader \(Int32 sessionId, String methodName, Int32 msgType, String headerName, String headerValue\)](#)
Add the SIP Message header into the specified outgoing SIP message.
- Int32 [removeAddedSipMessageHeader \(Int32 sipMessageHeaderId\)](#)
Remove the headers (custom header) added by addSipMessageHeader.
- Int32 [clearAddedSipMessageHeaders \(\)](#)
Clear the added extension headers (custom headers)

- Int32 [modifySipMessageHeader](#) (Int32 sessionId, String methodName, Int32 msgType, String headerName, String headerValue)
Modify the special SIP header value for every outgoing SIP message.
- Int32 [removeModifiedSipMessageHeader](#) (Int32 sipMessageHeaderId)
Remove the extension header (custom header) from every outgoing SIP message.
- Int32 [clearModifiedSipMessageHeaders](#) ()
Clear the modified headers value, and do not modify every outgoing SIP message header values any longer.
- Int32 [addSupportedMimeType](#) (String methodName, String mimeType, String subMimeType)
Set the SDK to receive the SIP messages that include special mime type.
- Int32 [setAudioSamples](#) (Int32 ptime, Int32 maxPtime)
Set the audio capture sample.
- Int32 [setAudioDeviceId](#) (Int32 recordingDeviceId, Int32 playoutDeviceId)
Set the audio device that will be used for audio call.
- Int32 [setVideoDeviceId](#) (Int32 deviceId)
Set the video device that will be used for video call.
- Int32 [setVideoResolution](#) (Int32 width, Int32 height)
Set the video capturing resolution.
- Int32 [setAudioBitrate](#) (Int32 sessionId, [AUDIOCODEC_TYPE](#) audioCodecType, Int32 bitrateKbps)
Set the audio bitrate.
- Int32 [setVideoBitrate](#) (Int32 sessionId, Int32 bitrateKbps)
Set the video bitrate.
- Int32 [setVideoFrameRate](#) (Int32 sessionId, Int32 frameRate)
Set the video frame rate.
- Int32 [sendVideo](#) (Int32 sessionId, Boolean sendState)
Send the video to remote side.
- void [muteMicrophone](#) (Boolean mute)
Mute the device microphone. It's unavailable for Android and iOS.
- void [muteSpeaker](#) (Boolean mute)
Mute the device speaker. It's unavailable for Android and iOS.
- void [setChannelOutputVolumeScaling](#) (Int32 sessionId, Int32 scaling)
- void [setChannelInputVolumeScaling](#) (Int32 sessionId, Int32 scaling)
- Int32 [setRemoteVideoWindow](#) (Int32 sessionId, IntPtr remoteVideoWindow)
Set the window for a session that is used to display the received remote video image.

- Int32 [displayLocalVideo](#) (Boolean state, Boolean mirror, IntPtr localVideoWindow)
Start/stop displaying the local video image.
- Int32 [setVideoNackStatus](#) (Boolean state)
Enable/disable the NACK feature (rfc6642) that helps to improve the video quality.
- Int32 [call](#) (String callee, Boolean sendSdp, Boolean videoCall)
Make a call.
- Int32 [rejectCall](#) (Int32 sessionId, int code)
rejectCall Reject the incoming call.
- Int32 [hangUp](#) (Int32 sessionId)
hangUp Hang up the call.
- Int32 [answerCall](#) (Int32 sessionId, Boolean videoCall)
answerCall Answer the incoming call.
- Int32 [updateCall](#) (Int32 sessionId, bool enableAudio, bool enableVideo)
Use the re-INVITE to update the established call.
- Int32 [hold](#) (Int32 sessionId)
To place a call on hold.
- Int32 [unHold](#) (Int32 sessionId)
Take off hold.
- Int32 [muteSession](#) (Int32 sessionId, Boolean muteIncomingAudio, Boolean muteOutgoingAudio, Boolean muteIncomingVideo, Boolean muteOutgoingVideo)
Mute the specified session audio or video.
- Int32 [forwardCall](#) (Int32 sessionId, String forwardTo)
Forward call to another one when receiving the incoming call.
- Int32 [pickupBLFCall](#) (String replaceDialogId, Boolean videoCall)
This function will be used for picking up a call based on the BLF (Busy Lamp Field) status.
- Int32 [sendDtmf](#) (Int32 sessionId, [DTMF_METHOD](#) dtmfMethod, int code, int dtmfDuration, bool playDtmfTone)
Send DTMF tone.
- Int32 [refer](#) (Int32 sessionId, String referTo)
Refer the current call to another one.
- Int32 [attendedRefer](#) (Int32 sessionId, Int32 replaceSessionId, String referTo)

- Int32 [attendedRefer2](#) (IntPtr libSDK, Int32 sessionId, Int32 replaceSessionId, String replaceMethod, String target, String referTo)
Make an attended refer with specified request line and specified method embedded into the "Refer-To" header.
- Int32 [outOfDialogRefer](#) (Int32 replaceSessionId, String replaceMethod, String target, String referTo)
Send an out of dialog REFER to replace the specified call.
- Int32 [acceptRefer](#) (Int32 referId, String referSignalingMessage)
Accept the REFER request, and a new call will be made if called this function. The function is usually called after onReceivedRefer callback event.
- Int32 [rejectRefer](#) (Int32 referId)
Reject the REFER request.
- Int32 [enableSendPcmStreamToRemote](#) (Int32 sessionId, Boolean state, Int32 streamSamplesPerSec)
Enable the SDK to send PCM stream data to remote side from another source instead of microphone.
- Int32 [sendPcmStreamToRemote](#) (Int32 sessionId, byte[] data, Int32 dataLength)
Send the audio stream in PCM format from another source instead of audio device capturing (microphone).
- Int32 [enableSendVideoStreamToRemote](#) (Int32 sessionId, Boolean state)
Enable the SDK send video stream data to remote side from another source instead of camera.
- Int32 [sendVideoStreamToRemote](#) (Int32 sessionId, byte[] data, Int32 dataLength, Int32 width, Int32 height)
Send the video stream to remote side.
- Int32 [enableAudioStreamCallback](#) (Int32 callbackObject, Int32 sessionId, Boolean enable, [DIRECTION_MODE](#) direction)
Enable/disable the audio stream callback.
- Int32 [enableVideoStreamCallback](#) (Int32 callbackObject, Int32 sessionId, [DIRECTION_MODE](#) direction)
Enable/disable the video stream callback.
- Int32 [startRecord](#) (Int32 sessionId, String recordFilePath, String recordFileName, Boolean appendTimestamp, [AUDIO_RECORDING_FILEFORMAT](#) audioFileFormat, [RECORD_MODE](#) audioRecordMode, [VIDEOCODEC_TYPE](#) videoFileCodecType, [RECORD_MODE](#) videoRecordMode)
Start recording the call.
- Int32 [stopRecord](#) (Int32 sessionId)
Stop record.
- Int32 [playVideoFileToRemote](#) (Int32 sessionId, String fileName, Boolean loop, Boolean playAudio)

Play an AVI file to remote party.

- Int32 [stopPlayVideoFileToRemote](#) (Int32 sessionId)
Stop playing video file to remote side.
- Int32 [playAudioFileToRemote](#) (Int32 sessionId, String fileName, Int32 fileSamplesPerSec, Boolean loop)
Play a wave file to remote party.
- Int32 [stopPlayAudioFileToRemote](#) (Int32 sessionId)
Stop playing wave file to remote side.
- Int32 [playAudioFileToRemoteAsBackground](#) (Int32 sessionId, String fileName, Int32 fileSamplesPerSec)
Play a wave file to remote party as conversation background sound.
- Int32 [stopPlayAudioFileToRemoteAsBackground](#) (Int32 sessionId)
Stop playing wave file to remote party as conversation background sound.
- Int32 [createAudioConference](#) ()
Create an audio conference. It will be failed if the existent conference is not ended yet.
- Int32 [createVideoConference](#) (IntPtr conferenceVideoWindow, Int32 width, Int32 height, Boolean displayLocalVideoInConference)
Create a video conference. It will be failed if the existent conference is not ended yet.
- void [destroyConference](#) ()
End the existent conference.
- Int32 [setConferenceVideoWindow](#) (IntPtr videoWindow)
Set the window for a conference that is used to display the received remote video image.
- Int32 [joinToConference](#) (Int32 sessionId)
Join a session into existent conference. If the call is in hold, it will be un-hold automatically.
- Int32 [removeFromConference](#) (Int32 sessionId)
Remove a session from an existent conference.
- Int32 [setAudioRtcpBandwidth](#) (Int32 sessionId, Int32 BitsRR, Int32 BitsRS, Int32 KBitsAS)
Set the audio RTCP bandwidth parameters to the RFC3556.
- Int32 [setVideoRtcpBandwidth](#) (Int32 sessionId, Int32 BitsRR, Int32 BitsRS, Int32 KBitsAS)
Set the video RTCP bandwidth parameters as the RFC3556.
- Int32 [getAudioStatistics](#) (Int32 sessionId, out Int32 sendBytes, out Int32 sendPackets, out Int32 sendPacketsLost, out Int32 sendFractionLost, out Int32 sendRttMS, out Int32 sendCodecType, out Int32 sendJitterMS, out Int32 sendAudioLevel, out Int32 recvBytes, out Int32 recvPackets, out Int32 recvPacketsLost, out Int32 recvFractionLost, out Int32 recvCodecType, out Int32 recvJitterMS, out Int32 recvAudioLevel)

Obtain the statistics of audio channel.

- Int32 [getVideoStatistics](#) (Int32 sessionId, out Int32 sendBytes, out Int32 sendPackets, out Int32 sendPacketsLost, out Int32 sendFractionLost, out Int32 sendRttMS, out Int32 sendCodecType, out Int32 sendFrameWidth, out Int32 sendFrameHeight, out Int32 sendBitrateBPS, out Int32 sendFramerate, out Int32 recvBytes, out Int32 recvPackets, out Int32 recvPacketsLost, out Int32 recvFractionLost, out Int32 recvCodecType, out Int32 recvFrameWidth, out Int32 recvFrameHeight, out Int32 recvBitrateBPS, out Int32 recvFramerate)
Obtain the RTP statistics of video.
- void [enableVAD](#) (Boolean state)
Enable/disable Voice Activity Detection (VAD).
- void [enableAEC](#) (Boolean state)
Enable/disable AEC (Acoustic Echo Cancellation).
- void [enableCNG](#) (Boolean state)
Enable/disable Comfort Noise Generator (CNG).
- void [enableAGC](#) (Boolean state)
Enable/disable Automatic Gain Control (AGC).
- void [enableANS](#) (Boolean state)
Enable/disable Audio Noise Suppression (ANS).
- Int32 [enableAudioQos](#) (Boolean state)
Set the DSCP (differentiated services code point) value of QoS (Quality of Service) for audio channel.
- Int32 [enableVideoQos](#) (Boolean state)
Set the DSCP (differentiated services code point) value of QoS (Quality of Service) for video channel.
- Int32 [setVideoMTU](#) (Int32 mtu)
Set the MTU size for video RTP packet.
- Int32 [sendOptions](#) (String to, String sdp)
Send OPTIONS message.
- Int32 [sendInfo](#) (Int32 sessionId, String mimeType, String subMimeType, String infoContents)
Send a INFO message to remote side in a call.
- Int32 [sendSubscription](#) (String to, String eventName)
Send a SUBSCRIBE message to subscribe an event.
- Int32 [terminateSubscription](#) (Int32 subscribeId)
Terminate the given subscription.

- Int32 [sendMessage](#) (Int32 sessionId, String mimeType, String subMimeType, byte[] message, Int32 messageLength)
Send a MESSAGE message to remote side in dialog.
- Int32 [sendOutOfDialogMessage](#) (String to, String mimeType, String subMimeType, Boolean isSMS, byte[] message, Int32 messageLength)
Send an out of dialog MESSAGE message to remote side.
- Int32 [setDefaultSubscriptionTime](#) (Int32 secs)
Set the default expiration time to be used when creating a subscription.
- Int32 [setDefaultPublicationTime](#) (Int32 secs)
Set the default expiration time to be used when creating a publication.
- Int32 [setPresenceMode](#) (Int32 mode)
Indicate the SDK uses the P2P mode for presence or presence agent mode.
- Int32 [presenceSubscribe](#) (String to, String subject)
Send a SUBSCRIBE message for subscribing the contact's presence status.
- Int32 [presenceTerminateSubscribe](#) (Int32 subscribeId)
Terminate the given presence subscription.
- Int32 [presenceRejectSubscribe](#) (Int32 subscribeId)
Reject a presence SUBSCRIBE request which is received from contact.
- Int32 [presenceAcceptSubscribe](#) (Int32 subscribeId)
Accept the presence SUBSCRIBE request which is received from contact.
- Int32 [setPresenceStatus](#) (Int32 subscribeId, String stateText)
Set the presence status.
- Int32 [getNumOfRecordingDevices](#) ()
Gets the count of audio devices available for audio recording.
- Int32 [getNumOfPlayoutDevices](#) ()
Gets the number of audio devices available for audio playout.
- Int32 [getRecordingDeviceName](#) (Int32 deviceIndex, StringBuilder nameUTF8, Int32 nameUTF8Length)
Gets the name of a specific recording device given by an index.
- Int32 [getPlayoutDeviceName](#) (Int32 deviceIndex, StringBuilder nameUTF8, Int32 nameUTF8Length)
Get the name of a specific playout device given by an index.
- Int32 [setSpeakerVolume](#) (Int32 volume)
Set the speaker volume level.

- Int32 [getSpeakerVolume \(\)](#)
Gets the speaker volume level.
- Int32 [setMicVolume \(Int32 volume\)](#)
Sets the microphone volume level.
- Int32 [getMicVolume \(\)](#)
Retrieves the current microphone volume.
- void [audioPlayLoopbackTest \(Boolean enable\)](#)
Use it for the audio device loop back test.
- Int32 [getNumOfVideoCaptureDevices \(\)](#)
Get the number of available capturing devices.
- Int32 [getVideoCaptureDeviceName \(Int32 deviceIndex, StringBuilder uniqueIdUTF8, Int32 uniqueIdUTF8Length, StringBuilder deviceNameUTF8, Int32 deviceNameUTF8Length\)](#)
Get the name of a specific video capture device given by an index.
- Int32 [showVideoCaptureSettingsDialogBox \(String uniqueIdUTF8, Int32 uniqueIdUTF8Length, String dialogTitle, IntPtr parentWindow, Int32 x, Int32 y\)](#)
Display the capture device property dialog box for the specified capture device.

The documentation for this class was generated from the following file:

- PortSIPLib.cs

PortSIP.SIPCallbackEvents Interface Reference

Public Member Functions

- Int32 [onRegisterSuccess](#) (Int32 callbackIndex, Int32 callbackObject, String statusText, Int32 statusCode, StringBuilder sipMessage)
- Int32 [onRegisterFailure](#) (Int32 callbackIndex, Int32 callbackObject, String statusText, Int32 statusCode, StringBuilder sipMessage)
- Int32 [onInviteIncoming](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String callerDisplayName, String caller, String calleeDisplayName, String callee, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [onInviteTrying](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onInviteSessionProgress](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsEarlyMedia, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [onInviteRinging](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String statusText, Int32 statusCode, StringBuilder sipMessage)
- Int32 [onInviteAnswered](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String callerDisplayName, String caller, String calleeDisplayName, String callee, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [onInviteFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code, StringBuilder sipMessage)
- Int32 [onInviteUpdated](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo, StringBuilder sipMessage)
- Int32 [onInviteConnected](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onInviteBeginingForward](#) (Int32 callbackIndex, Int32 callbackObject, String forwardTo)
- Int32 [onInviteClosed](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onDialogStateUpdated](#) (Int32 callbackIndex, Int32 callbackObject, String BLFMonitoredUri, String BLFDialgState, String BLFDialgId, String BLFDialgDirection)
- Int32 [onRemoteHold](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onRemoteUnHold](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String audioCodecNames, String videoCodecNames, Boolean existsAudio, Boolean existsVideo)
- Int32 [onReceivedRefer](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 referId, String to, String from, StringBuilder referSipMessage)
- Int32 [onReferAccepted](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onReferRejected](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code)
- Int32 [onTransferTrying](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onTransferRinging](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onACTVTransferSuccess](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
- Int32 [onACTVTransferFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String reason, Int32 code)
- Int32 [onReceivedSignaling](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, StringBuilder signaling)
- Int32 [onSendingSignaling](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, StringBuilder signaling)
- Int32 [onWaitingVoiceMessage](#) (Int32 callbackIndex, Int32 callbackObject, String messageAccount, Int32 urgentNewMessageCount, Int32 urgentOldMessageCount, Int32 newMessageCount, Int32 oldMessageCount)
- Int32 [onWaitingFaxMessage](#) (Int32 callbackIndex, Int32 callbackObject, String messageAccount, Int32 urgentNewMessageCount, Int32 urgentOldMessageCount, Int32 newMessageCount, Int32 oldMessageCount)
- Int32 [onRecvDtmfTone](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 tone)
- Int32 [onRecvOptions](#) (Int32 callbackIndex, Int32 callbackObject, StringBuilder optionsMessage)
- Int32 [onRecvInfo](#) (Int32 callbackIndex, Int32 callbackObject, StringBuilder infoMessage)

- Int32 [onRecvNotifyOfSubscription](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId, StringBuilder notifyMsg, byte[] contentData, Int32 contentLength)
 - Int32 [onSubscriptionFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId, Int32 statusCode)
 - Int32 [onSubscriptionTerminated](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId)
 - Int32 [onPresenceRecvSubscribe](#) (Int32 callbackIndex, Int32 callbackObject, Int32 subscribeId, String fromDisplayName, String from, String subject)
 - Int32 [onPresenceOnline](#) (Int32 callbackIndex, Int32 callbackObject, String fromDisplayName, String from, String stateText)
 - Int32 [onPresenceOffline](#) (Int32 callbackIndex, Int32 callbackObject, String fromDisplayName, String from)
 - Int32 [onRecvMessage](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String mimeType, String subMimeType, byte[] messageData, Int32 messageDataLength)
 - Int32 [onRecvOutOfDialogMessage](#) (Int32 callbackIndex, Int32 callbackObject, String fromDisplayName, String from, String toDisplayName, String to, String mimeType, String subMimeType, byte[] messageData, Int32 messageDataLength)
 - Int32 [onSendMessageSuccess](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 messageId)
 - Int32 [onSendMessageFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, Int32 messageId, String reason, Int32 code)
 - Int32 [onSendOutOfDialogMessageSuccess](#) (Int32 callbackIndex, Int32 callbackObject, Int32 messageId, String fromDisplayName, String from, String toDisplayName, String to)
 - Int32 [onSendOutOfDialogMessageFailure](#) (Int32 callbackIndex, Int32 callbackObject, Int32 messageId, String fromDisplayName, String from, String toDisplayName, String to, String reason, Int32 code)
 - Int32 [onPlayAudioFileFinished](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId, String fileName)
 - Int32 [onPlayVideoFileFinished](#) (Int32 callbackIndex, Int32 callbackObject, Int32 sessionId)
 - Int32 [onRTPPacketCallback](#) (IntPtr callbackObject, Int32 sessionId, Int32 mediaType, Int32 direction, byte[] RTPPacket, Int32 packetSize)
 - Int32 [onAudioRawCallback](#) (IntPtr callbackObject, Int32 sessionId, Int32 callbackType, byte[] data, Int32 dataLength, Int32 samplingFreqHz)
 - Int32 [onVideoRawCallback](#) (IntPtr callbackObject, Int32 sessionId, Int32 callbackType, Int32 width, Int32 height, byte[] data, Int32 dataLength)
-

Detailed Description

[SIPCallbackEvents](#) PortSIP VoIP SDK Callback events

The documentation for this interface was generated from the following file:

- SIPCallbackEvents.cs

Index

acceptRefer
 Refer functions, 37

Access SIP message header functions, 26
 displayLocalVideo, 29
 muteMicrophone, 28
 muteSpeaker, 29
 sendVideo, 28
 setAudioBitrate, 27
 setAudioDeviceId, 27
 setChannelInputVolumeScaling, 29
 setChannelOutputVolumeScaling, 29
 setRemoteVideoWindow, 29
 setVideoBitrate, 28
 setVideoDeviceId, 27
 setVideoFrameRate, 28
 setVideoNackStatus, 30
 setVideoResolution, 27

addAudioCodec
 Audio and video codecs functions, 16

Additional setting functions, 18
 addSipMessageHeader, 22
 clearAddedSipMessageHeaders, 23
 clearModifiedSipMessageHeaders, 24
 disableCallForward, 20
 disableSessionTimer, 21
 enableAutoCheckMwi, 21
 enableCallForward, 20
 enableSessionTimer, 20
 getSipMessageHeaderValue, 22
 modifySipMessageHeader, 23
 removeAddedSipMessageHeader, 23
 removeModifiedSipMessageHeader, 24
 setDoNotDisturb, 21
 setKeepAliveTime, 22
 setRtpKeepAlive, 21
 setRtpPortRange, 20
 setSrtpPolicy, 19

addSipMessageHeader
 Additional setting functions, 22

addSupportedMimeType
 Audio and video functions, 25

addVideoCodec
 Audio and video codecs functions, 16

answerCall
 Call functions, 32

attendedRefer
 Refer functions, 36

attendedRefer2
 Refer functions, 36

Audio and video codecs functions, 15
 addAudioCodec, 16
 addVideoCodec, 16
 isAudioCodecEmpty, 16
 isVideoCodecEmpty, 17
 setAudioCodecParameter, 17
 setAudioCodecPayloadType, 17

setVideoCodecParameter, 18
setVideoCodecPayloadType, 17

Audio and video functions, 24
 addSupportedMimeType, 25
 setAudioSamples, 25

Audio and video stream callback events, 76
 onAudioRawCallback, 76
 onVideoRawCallback, 76

Audio effect functions, 49
 enableAEC, 50
 enableAGC, 51
 enableANS, 51
 enableAudioQos, 51
 enableCNG, 50
 enableVAD, 50
 enableVideoQos, 51
 setVideoMTU, 51

AUDIO_RECORDING_FILEFORMAT
 PortSIP, 80

AUDIOCODEC_AMR
 PortSIP, 79

AUDIOCODEC_AMRWB
 PortSIP, 79

AUDIOCODEC_DTMF
 PortSIP, 80

AUDIOCODEC_G722
 PortSIP, 79

AUDIOCODEC_G7221
 PortSIP, 80

AUDIOCODEC_G729
 PortSIP, 79

AUDIOCODEC_GSM
 PortSIP, 79

AUDIOCODEC_ILBC
 PortSIP, 79

AUDIOCODEC_ISACSWB
 PortSIP, 80

AUDIOCODEC_ISACWB
 PortSIP, 79

AUDIOCODEC_OPUS
 PortSIP, 80

AUDIOCODEC_PCMA
 PortSIP, 79

AUDIOCODEC_PCMU
 PortSIP, 79

AUDIOCODEC_SPEEX
 PortSIP, 79

AUDIOCODEC_SPEEXWB
 PortSIP, 79

AUDIOCODEC_TYPE
 PortSIP, 79

audioPlayLoopbackTest
 Device Manage functions., 61

call
 Call functions, 31

Call events, 63

- onDialogStateChanged, 66
- onInviteAnswered, 65
- onInviteBeginningForward, 66
- onInviteClosed, 66
- onInviteConnected, 66
- onInviteFailure, 65
- onInviteIncoming, 64
- onInviteRinging, 65
- onInviteSessionProgress, 64
- onInviteTrying, 64
- onInviteUpdated, 65
- onRemoteHold, 66
- onRemoteUnHold, 66
- Call functions, 30
 - answerCall, 32
 - call, 31
 - forwardCall, 33
 - hangUp, 31
 - hold, 32
 - muteSession, 33
 - pickupBLFCall, 34
 - rejectCall, 31
 - sendDtmf, 34
 - unHold, 33
 - updateCall, 32
- clearAddedSipMessageHeaders
 - Additional setting functions, 23
- clearModifiedSipMessageHeaders
 - Additional setting functions, 24
- Conference functions, 45
 - createAudioConference, 45
 - createVideoConference, 45
 - destroyConference, 46
 - joinToConference, 46
 - removeFromConference, 46
 - setConferenceVideoWindow, 46
- createAudioConference
 - Conference functions, 45
- createVideoConference
 - Conference functions, 45
- destroyConference
 - Conference functions, 46
- Device Manage functions., 58
 - audioPlayLoopbackTest, 61
 - getMicVolume, 60
 - getNumOfLayoutDevices, 59
 - getNumOfRecordingDevices, 59
 - getNumOfVideoCaptureDevices, 61
 - getLayoutDeviceName, 59
 - getRecordingDeviceName, 59
 - getSpeakerVolume, 60
 - getVideoCaptureDeviceName, 61
 - setMicVolume, 60
 - setSpeakerVolume, 60
 - showVideoCaptureSettingsDialogBox, 61
- DIRECTION_INACTIVE
 - PortSIP, 81
- DIRECTION_MODE
 - PortSIP, 81
- DIRECTION_NONE
 - PortSIP, 81
- DIRECTION_RECV
 - PortSIP, 81
- DIRECTION_SEND
 - PortSIP, 81
- DIRECTION_SEND_RECV
 - PortSIP, 81
- disableCallForward
 - Additional setting functions, 20
- disableSessionTimer
 - Additional setting functions, 21
- displayLocalVideo
 - Access SIP message header functions, 29
- DTMF events, 70
 - onRecvDtmfTone, 70
- DTMF_INFO
 - PortSIP, 82
- DTMF_METHOD
 - PortSIP, 82
- DTMF_RFC2833
 - PortSIP, 82
- enable3GppTags
 - NIC and local IP functions, 14
- enableAEC
 - Audio effect functions, 50
- enableAGC
 - Audio effect functions, 51
- enableANS
 - Audio effect functions, 51
- enableAudioQos
 - Audio effect functions, 51
- enableAudioStreamCallback
 - RTP packets, Audio stream and video stream callback functions, 40
- enableAutoCheckMwi
 - Additional setting functions, 21
- enableCallbackSignaling
 - NIC and local IP functions, 14
- enableCallForward
 - Additional setting functions, 20
- enableCNG
 - Audio effect functions, 50
- enableEarlyMedia
 - NIC and local IP functions, 14
- enableReliableProvisional
 - NIC and local IP functions, 14
- enableRport
 - NIC and local IP functions, 13
- enableRtpCallback
 - NIC and local IP functions, 15
- enableSendPcmStreamToRemote
 - Send audio and video stream functions, 38
- enableSendVideoStreamToRemote
 - Send audio and video stream functions, 39
- enableSessionTimer
 - Additional setting functions, 20
- enableVAD
 - Audio effect functions, 50

enableVideoQos
 Audio effect functions, 51
enableVideoStreamCallback
 RTP packets, Audio stream and video stream callback functions, 41
FILEFORMAT_AMR
 PortSIP, 80
FILEFORMAT_WAVE
 PortSIP, 80
forwardCall
 Call functions, 33
getAudioStatistics
 RTP statistics functions, 48
getLocalIpAddress
 NIC and local IP functions, 12
getMicVolume
 Device Manage functions., 60
getNICNums
 NIC and local IP functions, 11
getNumOfPlayoutDevices
 Device Manage functions., 59
getNumOfRecordingDevices
 Device Manage functions., 59
getNumOfVideoCaptureDevices
 Device Manage functions., 61
getPlayoutDeviceName
 Device Manage functions., 59
getRecordingDeviceName
 Device Manage functions., 59
getSipMessageHeaderValue
 Additional setting functions, 22
getSpeakerVolume
 Device Manage functions., 60
getVersion
 Initialize and register functions, 10
getVideoCaptureDeviceName
 Device Manage functions., 61
getVideoStatistics
 RTP statistics functions, 49
hangUp
 Call functions, 31
hold
 Call functions, 32
INFO/OPTIONS message events, 71
 onRecvInfo, 71
 onRecvNotifyOfSubscription, 71
 onRecvOptions, 71
 onSubscriptionFailure, 72
 onSubscriptionTerminated, 72
initialize
 Initialize and register functions, 9
Initialize and register functions, 8
 getVersion, 10
 initialize, 9
 setLicenseKey, 10
isAudioCodecEmpty
 Audio and video codecs functions, 16
isVideoCodecEmpty
 Audio and video codecs functions, 17
joinToConference
 Conference functions, 46
modifySipMessageHeader
 Additional setting functions, 23
muteMicrophone
 Access SIP message header functions, 28
muteSession
 Call functions, 33
muteSpeaker
 Access SIP message header functions, 29
MWI events, 69
 onWaitingFaxMessage, 70
 onWaitingVoiceMessage, 69
NIC and local IP functions, 10
 enable3GppTags, 14
 enableCallbackSignaling, 14
 enableEarlyMedia, 14
 enableReliableProvisional, 14
 enableRport, 13
 enableRtpCallback, 15
 getLocalIpAddress, 12
 getNICNums, 11
 registerServer, 13
 setDisplayName, 12
 setInstanceId, 13
 setUser, 12
 unRegisterServer, 13
onACTVTransferFailure
 Refer events, 68
onACTVTransferSuccess
 Refer events, 68
onAudioRawCallback
 Audio and video stream callback events, 76
onDialogStateUpdated
 Call events, 66
onInviteAnswered
 Call events, 65
onInviteBeginingForward
 Call events, 66
onInviteClosed
 Call events, 66
onInviteConnected
 Call events, 66
onInviteFailure
 Call events, 65
onInviteIncoming
 Call events, 64
onInviteRinging
 Call events, 65
onInviteSessionProgress
 Call events, 64
onInviteTrying
 Call events, 64
onInviteUpdated
 Call events, 65
onPlayAudioFileFinished
 Play audio and video file finished events, 75
onPlayVideoFileFinished

Play audio and video file finished events, 75
 onPresenceOffline Presence events, 73
 onPresenceOnline Presence events, 73
 onPresenceRecvSubscribe Presence events, 72
 onReceivedRefer Refer events, 67
 onReceivedSignaling Signaling events, 69
 onRecvDtmfTone DTMF events, 70
 onRecvInfo INFO/OPTIONS message events, 71
 onRecvMessage Presence events, 73
 onRecvNotifyOfSubscription INFO/OPTIONS message events, 71
 onRecvOptions INFO/OPTIONS message events, 71
 onRecvOutOfDialogMessage Presence events, 73
 onReferAccepted Refer events, 67
 onReferRejected Refer events, 67
 onRegisterFailure Register events, 63
 onRegisterSuccess Register events, 62
 onRemoteHold Call events, 66
 onRemoteUnHold Call events, 66
 onRTPPacketCallback RTP callback events, 75
 onSendingSignaling Signaling events, 69
 onSendMessageFailure Presence events, 74
 onSendMessageSuccess Presence events, 73
 onSendOutOfDialogMessageFailure Presence events, 74
 onSendOutOfDialogMessageSuccess Presence events, 74
 onSubscriptionFailure INFO/OPTIONS message events, 72
 onSubscriptionTerminated INFO/OPTIONS message events, 72
 onTransferRingng Refer events, 68
 onTransferTrying Refer events, 68
 onVideoRawCallback Audio and video stream callback events, 76
 onWaitingFaxMessage

MWI events, 70
 onWaitingVoiceMessage MWI events, 69
 outOfDialogRefer Refer functions, 37
 pickupBLFCall Call functions, 34
 Play audio and video file finished events, 74
 onPlayAudioFileFinished, 75
 onPlayVideoFileFinished, 75
 Play audio and video file to remote functions, 42
 playAudioFileToRemote, 43
 playAudioFileToRemoteAsBackground, 44
 playVideoFileToRemote, 43
 stopPlayAudioFileToRemote, 44
 stopPlayAudioFileToRemoteAsBackground, 44
 stopPlayVideoFileToRemote, 43
 playAudioFileToRemote
 Play audio and video file to remote functions, 43
 playAudioFileToRemoteAsBackground
 Play audio and video file to remote functions, 44
 playVideoFileToRemote
 Play audio and video file to remote functions, 43
 PortSIP, 78
 AUDIO_RECORDING_FILEFORMAT, 80
 AUDIOCODEC_AMR, 79
 AUDIOCODEC_AMRWB, 79
 AUDIOCODEC_DTMF, 80
 AUDIOCODEC_G722, 79
 AUDIOCODEC_G7221, 80
 AUDIOCODEC_G729, 79
 AUDIOCODEC_GSM, 79
 AUDIOCODEC_ILBC, 79
 AUDIOCODEC_ISACSWB, 80
 AUDIOCODEC_ISACWB, 79
 AUDIOCODEC_OPUS, 80
 AUDIOCODEC_PCMA, 79
 AUDIOCODEC_PCMU, 79
 AUDIOCODEC_SPEEX, 79
 AUDIOCODEC_SPEEXWB, 79
 AUDIOCODEC_TYPE, 79
 DIRECTION_INACTIVE, 81
 DIRECTION_MODE, 81
 DIRECTION_NONE, 81
 DIRECTION_RECV, 81
 DIRECTION_SEND, 81
 DIRECTION_SEND_RECV, 81
 DTMF_INFO, 82
 DTMF_METHOD, 82
 DTMF_RFC2833, 82
 FILEFORMAT_AMR, 80
 FILEFORMAT_WAVE, 80
 RECORD_BOTH, 81

RECORD_MODE, 80
 RECORD_NONE, 81
 RECORD_RECV, 81
 RECORD_SEND, 81
 SESSION_REFRESH_UAC, 82
 SESSION_REFRESH_UAS, 82
 SESSION_REFRESH_MODE, 82
 SRTP_POLICY, 81
 SRTP_POLICY_FORCE, 81
 SRTP_POLICY_NONE, 81
 SRTP_POLICY_PREFER, 81
 TRANSPORT_PERS, 82
 TRANSPORT_TCP, 82
 TRANSPORT_TLS, 82
 TRANSPORT_TYPE, 81
 TRANSPORT_UDP, 82
 VIDEO_CODE_NONE, 80
 VIDEO_CODEC_H263, 80
 VIDEO_CODEC_H263_1998, 80
 VIDEO_CODEC_H264, 80
 VIDEO_CODEC_I420, 80
 VIDEO_CODEC_VP8, 80
 VIDEO_CODEC_VP9, 80
 VIDEOCODEC_TYPE, 80
 PortSIP.PortSIP_Errors, 83
 PortSIP.PortSIPLib, 86
 PortSIP.SIPCallbackEvents, 96
 Presence events, 72

- onPresenceOffline, 73
- onPresenceOnline, 73
- onPresenceRecvSubscribe, 72
- onRecvMessage, 73
- onRecvOutOfDialogMessage, 73
- onSendMessageFailure, 74
- onSendMessageSuccess, 73
- onSendOutOfDialogMessageFailure, 74
- onSendOutOfDialogMessageSuccess, 74

 Presence functions, 56

- presenceAcceptSubscribe, 57
- presenceRejectSubscribe, 57
- presenceSubscribe, 56
- presenceTerminateSubscribe, 56
- setPresenceStatus, 57

 presenceAcceptSubscribe

- Presence functions, 57

 presenceRejectSubscribe

- Presence functions, 57

 presenceSubscribe

- Presence functions, 56

 presenceTerminateSubscribe

- Presence functions, 56

 Record functions, 41

- startRecord, 42
- stopRecord, 42

 RECORD_BOTH

- PortSIP, 81

 RECORD_MODE

- PortSIP, 80

 RECORD_NONE

- PortSIP, 81

 RECORD_RECV

- PortSIP, 81

 RECORD_SEND

- PortSIP, 81

 refer

- Refer functions, 35

 Refer events, 67

- onACTVTransferFailure, 68
- onACTVTransferSuccess, 68
- onReceivedRefer, 67
- onReferAccepted, 67
- onReferRejected, 67
- onTransferRinging, 68
- onTransferTrying, 68

 Refer functions, 35

- acceptRefer, 37
- attendedRefer, 36
- attendedRefer2, 36
- outOfDialogRefer, 37
- refer, 35
- rejectRefer, 37

 Register events, 62

- onRegisterFailure, 63
- onRegisterSuccess, 62

 registerServer

- NIC and local IP functions, 13

 rejectCall

- Call functions, 31

 rejectRefer

- Refer functions, 37

 removeAddedSipMessageHeader

- Additional setting functions, 23

 removeFromConference

- Conference functions, 46

 removeModifiedSipMessageHeader

- Additional setting functions, 24

 RTP and RTCP QOS functions, 47

- setAudioRtcpBandwidth, 47
- setVideoRtcpBandwidth, 47

 RTP callback events, 75

- onRTPPacketCallback, 75

 RTP packets, Audio stream and video stream

- callback functions, 40
 - enableAudioStreamCallback, 40
 - enableVideoStreamCallback, 41

 RTP statistics functions, 48

- getAudioStatistics, 48
- getVideoStatistics, 49

 SDK Callback events, 62
 SDK functions, 8
 Send audio and video stream functions, 37

- enableSendPcmStreamToRemote, 38
- enableSendVideoStreamToRemote, 39
- sendPcmStreamToRemote, 38
- sendVideoStreamToRemote, 39

 Send OPTIONS/INFO/MESSAGE functions, 52

- sendInfo, 53
- sendMessage, 54
- sendOptions, 53

sendOutOfDialogMessage, 54
 sendSubscription, 53
 setDefaultPublicationTime, 55
 setDefaultSubscriptionTime, 55
 setPresenceMode, 55
 terminateSubscription, 54
sendDtmf
 Call functions, 34
sendInfo
 Send OPTIONS/INFO/MESSAGE functions, 53
sendMessage
 Send OPTIONS/INFO/MESSAGE functions, 54
sendOptions
 Send OPTIONS/INFO/MESSAGE functions, 53
sendOutOfDialogMessage
 Send OPTIONS/INFO/MESSAGE functions, 54
sendPcmStreamToRemote
 Send audio and video stream functions, 38
sendSubscription
 Send OPTIONS/INFO/MESSAGE functions, 53
sendVideo
 Access SIP message header functions, 28
sendVideoStreamToRemote
 Send audio and video stream functions, 39
SESSION_REFERESH_UAC
 PortSIP, 82
SESSION_REFERESH_UAS
 PortSIP, 82
SESSION_REFRESH_MODE
 PortSIP, 82
setAudioBitrate
 Access SIP message header functions, 27
setAudioCodecParameter
 Audio and video codecs functions, 17
setAudioCodecPayloadType
 Audio and video codecs functions, 17
setAudioDeviceId
 Access SIP message header functions, 27
setAudioRtcpBandwidth
 RTP and RTCP QOS functions, 47
setAudioSamples
 Audio and video functions, 25
setChannelInputVolumeScaling
 Access SIP message header functions, 29
setChannelOutputVolumeScaling
 Access SIP message header functions, 29
setConferenceVideoWindow
 Conference functions, 46
setDefaultPublicationTime
 Send OPTIONS/INFO/MESSAGE functions, 55
setDefaultSubscriptionTime
 Send OPTIONS/INFO/MESSAGE functions, 55
setDisplayName
 NIC and local IP functions, 12
setDoNotDisturb
 Additional setting functions, 21
setInstanceId
 NIC and local IP functions, 13
setKeepAliveTime
 Additional setting functions, 22
setLicenseKey
 Initialize and register functions, 10
setMicVolume
 Device Manage functions., 60
setPresenceMode
 Send OPTIONS/INFO/MESSAGE functions, 55
setPresenceStatus
 Presence functions, 57
setRemoteVideoWindow
 Access SIP message header functions, 29
setRtpKeepAlive
 Additional setting functions, 21
setRtpPortRange
 Additional setting functions, 20
setSpeakerVolume
 Device Manage functions., 60
setSrtpPolicy
 Additional setting functions, 19
setUser
 NIC and local IP functions, 12
setVideoBitrate
 Access SIP message header functions, 28
setVideoCodecParameter
 Audio and video codecs functions, 18
setVideoCodecPayloadType
 Audio and video codecs functions, 17
setVideoDeviceId
 Access SIP message header functions, 27
setVideoFrameRate
 Access SIP message header functions, 28
setVideoMTU
 Audio effect functions, 51
setVideoNackStatus
 Access SIP message header functions, 30
setVideoResolution
 Access SIP message header functions, 27
setVideoRtcpBandwidth
 RTP and RTCP QOS functions, 47
showVideoCaptureSettingsDialogBox
 Device Manage functions., 61
Signaling events, 68
 onReceivedSignaling, 69
 onSendingSignaling, 69
SRTP_POLICY
 PortSIP, 81
SRTP_POLICY_FORCE
 PortSIP, 81
SRTP_POLICY_NONE
 PortSIP, 81

SRTP_POLICY_PREFER
 PortSIP, 81

startRecord
 Record functions, 42

stopPlayAudioFileToRemote
 Play audio and video file to remote
 functions, 44

stopPlayAudioFileToRemoteAsBackground
 Play audio and video file to remote
 functions, 44

stopPlayVideoFileToRemote
 Play audio and video file to remote
 functions, 43

stopRecord
 Record functions, 42

terminateSubscription
 Send OPTIONS/INFO/MESSAGE
 functions, 54

TRANSPORT_PERS
 PortSIP, 82

TRANSPORT_TCP
 PortSIP, 82

TRANSPORT_TLS
 PortSIP, 82

TRANSPORT_TYPE
 PortSIP, 81

PortSIP, 81

TRANSPORT_UDP
 PortSIP, 82

unHold
 Call functions, 33

unRegisterServer
 NIC and local IP functions, 13

updateCall
 Call functions, 32

VIDEO_CODE_NONE
 PortSIP, 80

VIDEO_CODEC_H263
 PortSIP, 80

VIDEO_CODEC_H263_1998
 PortSIP, 80

VIDEO_CODEC_H264
 PortSIP, 80

VIDEO_CODEC_I420
 PortSIP, 80

VIDEO_CODEC_VP8
 PortSIP, 80

VIDEO_CODEC_VP9
 PortSIP, 80

VIDEOCODEC_TYPE
 PortSIP, 80